



770-413-9126 · [wscmotorsports.com](http://wscmotorsports.com) · [sales@wscmotorsports.com](mailto:sales@wscmotorsports.com)

**January 2005**  
**ONLINE CATALOG**

**Chevrolet Restoration Parts Catalog**

**Chevrolet - GMC**  
**1968 - 72**

**Chevelle / El Camino / Monte Carlo / GMC Sprint**

**1968 - 1969 - 1970 - 1971 - 1972**  
**Chevrolet**  
**Chevelle / El Camino / Monte Carlo / GMC Sprint**

<b>2005 Catalog (Rev 0305)</b>				
Picture	Part #	Application / Description	Ship By	Price
<b>Front Bumpers</b>				
	4032-000-68	1968	FedEx/UPS	\$ 199.95 ea
	4032-000-69	1969	FedEx/UPS	\$ 199.95 ea
	4033-000-70	1970 Chevelle only	FedEx/UPS	\$ 199.95 ea
	4060-000-70	1970 Monte Carlo / El Camino only	FedEx/UPS	\$ 199.95 ea
	4033-000-71	1971-72 Chevelle / El Camino only	FedEx/UPS	\$ 199.95 ea
	4060-000-71	1971 Monte Carlo	FedEx/UPS	Inquire
	4060-000-72	1972 Monte Carlo	FedEx/UPS	Inquire
<b>Front Bumper Bolt Kits - set of bolts, nuts, and washers</b>				
	4031-001-671S	1968-69 Chevelle / El Camino (28 pieces)	FedEx/UPS	\$ 19.95 kit
	4033-001-701S	1970-72 Chevelle / El Camino / Monte Carlo / Sprint (32 pieces)	FedEx/UPS	\$ 19.95 kit
<b>Front Bumper Mounting Bracket Hardware Kits - mount brackets to frame</b>				
	4032-005-681S	1968-69 Chevelle / El Camino (16 pieces)	FedEx/UPS	\$ 29.95 kit
	4033-005-702S	1970-72 Chevelle / El Camino / Sprint (16 pieces)	FedEx/UPS	\$ 19.95 kit
	4020-005-693S	1970-72 Monte Carlo (16 pieces)	FedEx/UPS	\$ 19.95 kit
	4033-005-703S	1970-72 Chevelle / El Camino / Sprint / Monte Carlo Outer Pad Bracket Hardware Kit (4 pieces)	FedEx/UPS	\$ 7.95 kit
<b>Front Bumper to Grille Fillers</b>				
	4032-020-68	1968	FedEx/UPS	\$ 99.95 ea
	4032-020-69	1969 <i>NOTE: Lower grille mounting brackets not included.</i>	FedEx/UPS	\$ 99.95 ea
	4033-020-70	1970 Chevelle / El Camino, 1970-72 Monte Carlo	FedEx/UPS	\$ 99.95 ea
<b>Header Panels</b>				
	4032-030-68	1968-69	FedEx/UPS	\$ 139.95 ea
<b>Header Panel Emblems</b>				
	4032-031-68	1968-69 "Chevelle" Header Panel Emblem	FedEx/UPS	\$ 24.95 ea
	4032-031-69	1969 Chevelle "BY CHEVROLET" Header Panel Emblem	FedEx/UPS	\$ 19.95 ea
	4020-031-671	1969 Wagon "Chevrolet" Header Panel Emblem	FedEx/UPS	\$ 12.95 ea
<b>Front Grilles</b>				
	4032-050-68	1968 (except SS-396) Grille (silver)	FedEx/UPS	Inquire
	4032-050-681	1968 SS-396 Grille (black)	FedEx/UPS	Inquire
	4032-050-68S	1968 Grille Hardware Kit	FedEx/UPS	\$ 9.95 kit
	4032-050-691	1969 300 Deluxe / El Camino Grille (black / silver) (without center molding holes)	FedEx/UPS	Inquire

	4032-050-692	1969 Malibu / El Camino Custom Grille (silver) (with center molding holes)	FedEx/UPS	Inquire
	4032-050-693	1969 SS-396 Grille (black / silver) (with center molding holes)	FedEx/UPS	Inquire
	4032-050-694S	1969 Grille Hardware Kit	FedEx/UPS	\$ 12.50 kit
	4033-050-701	1970 Chevelle / El Camino (except SS) Grille (silver)	FedEx/UPS	Inquire
	4033-050-702	1970 Chevelle / El Camino SS Grille (Black)	FedEx/UPS	\$ 199.95 ea
	4033-050-70S	1970 Grille Hardware Kit	FedEx/UPS	\$ 9.95 kit
	4033-050-71	1971 Chevelle / El Camino (except SS) Grille (silver)	FedEx/UPS	\$ 149.95 ea
	4033-050-711	1971 Chevelle / El Camino SS Grille (black)	FedEx/UPS	Inquire
	4033-050-71S	1971-72 Grille Hardware Kit	FedEx/UPS	\$ 12.50 kit
	4033-050-72	1972 Chevelle / El Camino (no moldings installed)	FedEx/UPS	\$ 99.95 ea
	4033-050-721	1972 Chevelle / El Camino (Black) Heavy Chevy / SS (upper and lower moldings installed)	FedEx/UPS	\$ 134.95 ea
	4033-050-722	1972 Chevelle / El Camino (Black) Malibu / El Camino Custom / Sprint Custom (upper, center, and lower moldings installed)	FedEx/UPS	\$ 159.95 ea
<b>Front Grille Mounting Brackets</b>				
	4032-053-691P	1969 Upper Grille Mounting Brackets, LH / RH pair	FedEx/UPS	\$ 19.95 pr
<b>Front Grille Moldings</b>				
	4032-055-68	1968-69 Header Molding	FedEx/UPS	\$ 49.95 ea
	4032-055-68S	1968-69 Header Molding / Fender Eyebrow Molding Hardware Kit (12 pieces)	FedEx/UPS	\$ 9.95 kit
	4032-055-692	1969 Outer Upper Grille Moldings, LH = RH (use 2 per car) (between headlamps)	FedEx/UPS	\$ 14.95 ea
	4032-056-681P	1968 (except SS-396) Grille Extensions LH / RH pair (silver)	FedEx/UPS	Inquire
	4032-056-682P	1968 SS-396 Grille Extensions LH / RH pair (black)	FedEx/UPS	\$ 32.50 pr
	4032-055-681P	1968 Lower Grille Extension Moldings, LH / RH pair	FedEx/UPS	\$ 29.95 pr
	4032-056-68S	1968 Grille Extension Hardware Kit (16 pieces)	FedEx/UPS	\$ 9.95 kit
	4032-056-69P	1969 (except SS-396) Grille Extensions, LH / RH pair (silver)	FedEx/UPS	Inquire
	4032-056-691P	1969 SS-396 Grille Extensions, LH / RH pair (black)	FedEx/UPS	Inquire
	4032-055-69L / R	1969 Lower Grille Extension Moldings, LH / RH	FedEx/UPS	\$ 19.95 ea
	4032-056-69S	1969 Grille Extension Hardware Kit (6-pieces)	FedEx/UPS	\$ 7.95 kit
	4032-055-691	1969 Lower Center Grille Molding - New Tooling!	FedEx/UPS	\$ 59.95 ea
	4032-055-693	1969 Malibu / Concours / El Camino Custom Center Grille Molding <b>New Tooling!</b>	FedEx/UPS	\$ 44.95 ea
	4032-055-69S	1969 Grille Molding Hardware Kit	FedEx/UPS	\$ 12.50 kit

	4033-055-701S	1970 Chevelle / El Camino (except Malibu / El Camino Custom) Grille Moldings (8-piece set)	FedEx/UPS	\$ 59.95 set
	4033-055-702S	1970 Malibu / El Camino Custom Grille Moldings (10-piece set)	FedEx/UPS	\$ 64.95 set
	4033-055-704P	1970 Malibu / El Camino Custom Under Headlamp Moldings, LH / RH pair	FedEx/UPS	\$ 59.95 pr
	4033-055-71S	1971 Chevelle / El Camino Grille Moldings (5-piece set)	FedEx/UPS	\$ 107.50 set
	4033-055-721	1972 Chevelle / El Camino Upper Grille Molding	FedEx/UPS	\$ 34.95 ea
	4033-055-722	1972 Malibu / El Camino Custom Center Grille Molding (use 2 per car)	FedEx/UPS	\$ 34.95 ea
	4033-055-723	1972 Chevelle / El Camino Lower Grille Molding	FedEx/UPS	\$ 34.95 ea
<b>Grille Emblems</b>				
	4033-058-702	1970 "Chevelle"	FedEx/UPS	\$ 24.95 ea
	4033-058-703	1970 Chevelle / El Camino "SS" (new GM)	FedEx/UPS	\$ 49.95 ea
	4033-058-712	1971 "Chevelle"	FedEx/UPS	\$ 24.95 ea
	4033-058-721	1972 "Chevelle"	FedEx/UPS	\$ 24.95 ea
<b>Headlamp Bezels</b>				
	4032-060-68S	1968 Headlamp Bezels, Set of 4 LH / RH Inner / Outer	FedEx/UPS	Inquire
	4032-060-681S	1968 Headlamp Bezel Hardware Kit (16 pieces)	FedEx/UPS	\$ 9.95 kit
	4032-060-69S	1969 Headlamp Bezels, Set of 4 LH / RH Inner / Outer (modify outboard for headlamp washers if needed)	FedEx/UPS	\$ 179.95 set
	4032-060-693S	1969 Headlamp Bezel Hardware Kit	FedEx/UPS	\$ 12.50 kit
	4032-060-694S	1969 Headlamp Bezel Bracket Hardware Kit	FedEx/UPS	\$ 7.95 kit
	4012-060-691S	1969 Headlamp Washer Set - Set of 4 chrome nozzles, washers, and nuts	FedEx/UPS	\$ 29.95 set
	4033-060-70S	1970 Chevelle / El Camino Headlamp Bezels, Set of 4 LH / RH Inner / Outer	FedEx/UPS	\$ 129.95 set
	4033-060-701S	1970 Chevelle / El Camino Headlamp Bezel Hardware Kit (16 pieces)	FedEx/UPS	\$ 9.95 kit
	4060-060-70S	1970-72 Monte Carlo, 1971-72 Chevelle / El Camino Headlamp Bezel Hardware Kit (12 pieces)	FedEx/UPS	\$ 5.95 kit
	4033-060-71P	1971 Chevelle / El Camino, LH / RH pair	FedEx/UPS	\$ 119.95 pr
	4033-060-72P	1972 Chevelle / El Camino LH / RH pair (paint black accents for SS models)	FedEx/UPS	Inquire
<b>Headlamp Retaining Rings</b>				
	4032-062-68	1968-70 Chevelle / El Camino (use 4)	FedEx/UPS	\$ 29.95 ea
	4010-062-62	1970 Monte Carlo (use 2)	FedEx/UPS	\$ 10.95 ea
<b>Headlamp Mounting Rings</b>				
	4047-063-741L	1968-70 Chevelle / El Camino Outer LH	FedEx/UPS	\$ 34.95 ea
	4047-063-742L / R	1968-70 Chevelle / El Camino Inner LH / RH	FedEx/UPS	\$ 34.95 ea
	4140-063-47	1970 Monte Carlo RH	FedEx/UPS	\$ 34.95 ea
<b>Headlamp Adjusting Hardware</b>				
	4032-069-69S	1968-70 Chevelle / El Camino Headlamp Adjuster Kit (20 pieces)	FedEx/UPS	\$ 19.95 kit

	4020-069-69S	1970 Monte Carlo Headlamp Adjuster Kit (10 pieces)	FedEx/UPS	\$ 9.95 kit
	4034-069-731S	1971-72 Chevelle / El Camino Headlamp Adjuster Kit (10 pieces)	FedEx/UPS	\$ 9.95 kit
	4021-069-71S	1971-72 Monte Carlo Headlamp Adjuster Kit (10 pieces)	FedEx/UPS	\$ 9.95 kit
	HWB2106	1968-70 Screw, box of 25	FedEx/UPS	\$ 9.95 box
	HWB2107	1971-72 Screw, box of 50	FedEx/UPS	\$ 12.50 box
	HWB2104	1968-72 Nut, box of 50	FedEx/UPS	\$ 9.95 box
	HWB2114	1968-70 Chevelle / El Camino Spring, box of 25	FedEx/UPS	\$ 12.50 box
	HW2102	1970 Monte Carlo Spring (use 2 per car)	FedEx/UPS	\$ 2.95 ea
	HWB2155	1971-72 Monte Carlo Spring, box of 25	FedEx/UPS	\$ 9.95 box
<b>Park Lamp Lenses and Screw Kit</b>				
	4082-070-69P	1969 El Camino Park Lamp Lenses, LH / RH pair (limited supply)	FedEx/UPS	\$ 34.95 pr
	4010-070-621S	1968-69 Park Lamp Screw Set (set of 4 special screws)	FedEx/UPS	\$ 4.95 set
	4083-070-71P	1971 El Camino Park Lamp Lenses, LH / RH pair (limited supply)	FedEx/UPS	\$ 59.95 pr
	4083-070-721P	1972 El Camino Park Lamp Lenses (amber), LH / RH pair (limited supply)	FedEx/UPS	\$ 59.95 pr
<b>Park Lamp Assemblies</b>				
	4032-071-681	1968 Chevelle / El Camino Park Lamp Assembly (use 2 per car) (modify for lamp monitors)	FedEx/UPS	\$ 59.95 ea
	4032-071-691L / R	1969 Chevelle (except SS) Park Lamp Assembly, LH / RH (modify for lamp monitors)	FedEx/UPS	\$ 59.95 ea
	4032-071-692L / R	1969 Chevelle SS-396 Park Lamp Assembly, LH / RH (modify for lamp monitors) (with stainless steel bezels)	FedEx/UPS	\$ 69.95 ea
	4082-071-69L / R	1969 El Camino Park Lamp Assembly, LH / RH (modify for lamp monitors) (limited supply)	FedEx/UPS	\$ 59.95 ea
	4033-071-702	1970 Chevelle SS Park Lamp Assembly, LH = RH (clear lenses)	FedEx/UPS	\$ 59.95 ea
	4083-071-70	1970 El Camino Park Lamp Assembly, LH = RH (use 2 per car) (limited supply)	FedEx/UPS	\$ 59.95 ea
<b>Park Lamp Bezels</b>				
	4033-076-71L / R	1971 Chevelle except Wagon / El Camino / Sprint, LH / RH	FedEx/UPS	\$ 39.95 ea
	4083-076-71L / R	1971 Chevelle Wagon / El Camino / Sprint, LH / RH	FedEx/UPS	\$ 39.95 ea
	4033-076-71S	1971-72 Chevelle / El Camino Park Lamp Bezel Hardware Kit (16 pieces)	FedEx/UPS	\$ 14.95 kit
	4033-076-72L / R	1972 Chevelle except Wagon / El Camino / Sprint, LH / RH	FedEx/UPS	\$ 39.95 ea
	4083-076-72L / R	1972 Chevelle Wagon / El Camino / Sprint, LH / RH	FedEx/UPS	\$ 39.95 ea
<b>Front Fenders</b>				
	4032-100-68L / R	1968, LH / RH	Truck	Inquire
	4032-100-69L / R	1969, LH / RH	Truck	Inquire

	4033-100-70L / R	1970 Chevelle (except wagon / El Camino) LH / RH. <b>Best Quality!</b>	Truck	\$ 329.95 ea-
	4033-100-71L / R	1971-72 Chevelle (except wagon / El Camino / Sprint) LH / RH. <b>Best Quality!</b>	Truck	\$ 329.95 ea
	4083-100-70L / R	1970 Chevelle Wagon / El Camino, LH / RH	Truck	\$ 349.95 ea
	4083-100-71L / R	1971-72 Chevelle Wagon / El Camino / Sprint, LH / RH	Truck	\$ 349.95 ea
<b>Front Fender Extension Hardware Kits</b>				
	4033-110-70S	1970 Chevelle / El Camino Fender Extension Hardware Kit (34 pieces)	FedEx/UPS	\$ 19.95 kit
	4033-110-711S	1971-72 Chevelle / El Camino Fender Extension Hardware Kit (12 pieces)	FedEx/UPS	\$ 5.95 kit
	4033-110-712S	1971-72 Chevelle / El Camino Fender Extension Top Bracket Hardware Kit (4 pieces)	FedEx/UPS	\$ 5.95 kit
<b>Front Fender Moldings</b>				
	4032-115-681P	1968-72 LH / RH pair (fits upper rear corner) (includes seals)	FedEx/UPS	\$ 24.95 set
	4032-115-683P	1968 Malibu / Concours / SS-396 Eyebrow Moldings, LH / RH pair	FedEx/UPS	Inquire
	4032-115-691P	1969 300 Deluxe / SS-396 Eyebrow Moldings, LH / RH pair	FedEx/UPS	\$ 49.95 pr
	4032-115-692R	1969 Malibu / Concours Eyebrow Moldings, RH only	FedEx/UPS	\$ 39.95 ea
<b>Front Fender Braces</b>				
	4033-120-70	1970-72 (use 2)	FedEx/UPS	\$ 7.50 ea
<b>Front Fender Emblems</b>				
	4032-130-692	1969-72 Chevelle / El Camino SS "S" (use 4per car)	FedEx/UPS	\$ 7.50 ea
	4032-130-693	1969-70 Chevelle / El Camino SS-396 "396" (use 2 per car) (new GM)	FedEx/UPS	\$ 49.95 ea
	4033-130-705P	1970-72 Chevelle / El Camino SS-454 "454" (LH / RH pair)	FedEx/UPS	\$ 29.95 pr
	4033-130-711	1971-72 Chevelle "Malibu" (use 2 per car) (new GM)	FedEx/UPS	\$ 29.95 ea
	4083-130-703	1970-72 El Camino "350" (use 2 per car) (new GM)	FedEx/UPS	\$ 49.95 ea
<b>Front Side Markers - See side marker kits in section 905!</b>				
	4012-140-68	1968 (use 2) (clear lens)	FedEx/UPS	\$ 5.95 ea
	4012-140-681	1968 (use 2) (clear lens) (with socket and bulb)	FedEx/UPS	\$ 19.95 ea
	4020-140-69	1969 (use 2) (amber lens)	FedEx/UPS	\$ 12.50 ea
<b>Front Side Marker Bezels - See side marker kits in section 905!</b>				
	4012-626-68	1968 L6 models (use 2)	FedEx/UPS	\$ 4.95 ea
	4032-141-69	1969 L6 or SS-396 models (use 2)	FedEx/UPS	\$ 24.95 ea
<b>Front Fender Tie Bar</b>				
	4033-150-70	1970-72 Chevelle / El Camino	FedEx/UPS	\$ 49.95 ea
<b>Lower Rear Fender Patch Panels</b>				
	4033-190-701L / R	1970-72 Chevelle (except Wagon / El Camino / Sprint), LH / RH, measures 17" high x 15" long - New Tooling! Improved Quality!	FedEx/UPS	\$ 39.95 ea

<b>Hoods</b>				
	4032-200-69	1969 SS-396 (can fit 1968 models if 1969 hood hinges are used) <b>Best Quality! New Tooling!</b>	Truck	\$ 324.95 ea
	4032-200-691	1969 2" Steel Cowl Induction Style (can fit 1968 models if 1969 hood hinges are used) - (+ additional \$20.00 pallet charge) <i>NOTE: Use with our rear edge molding set 4032-250-69S below.</i>	Truck	\$ 449.95 ea
	4033-200-70	1970-72 Chevelle Heavy Chevy / SS / Sprint SP (non-functional) - <b>Best Quality!</b>	Truck	\$ 349.95 ea
	4033-200-701	1970-72 Chevelle SS / Sprint SP (functional Cowl Induction) - <b>Best Quality!</b>	Truck	\$ 349.95 ea
<b>Hood Insulation Clips</b>				
	HWB2401	1970-72 Monte Carlo Hood Insulation Clips, box of 25	FedEx/UPS	\$ 5.95 box
<b>Hood Adjustment Bumpers</b>				
	4010-205-62P	1968-72 Hood Adjustment Rubber Bumpers (pair for one car)	FedEx/UPS	\$ 2.50 pr
	4010-205-642S	1968-72 Hood Leveler Kit (Bumpers, Screws, and Nuts for one car)	FedEx/UPS	\$ 14.95 kit
	4020-206-67P	1968-72 Hood / Fender Side Bumpers (use 2 pair per car)	FedEx/UPS	\$ 4.95 pr
<b>Hood Hinges</b>				
	4033-210-70L / R	1970-72 LH / RH (new GM)	FedEx/UPS	\$ 99.95 ea
<b>Hood Hinge Springs</b>				
	4010-211-65	1968-72 Chevelle / El Camino (except SS / Sprint SP or Monte Carlo) (use 2 per car)	FedEx/UPS	\$ 19.95 ea
	4021-211-81	1970 Monte Carlo (use 2 per car)	FedEx/UPS	\$ 19.95 ea
	4010-211-64	1971-72 Chevelle / El Camino SS / Sprint SP, 1971-72 Monte Carlo (use 2 per car)	FedEx/UPS	\$ 19.95 ea
<b>Hood Emblems</b>				
	4033-215-701	1970-72 Cowl Induction Hood Emblem ("COWL") (use 2 per car) (new GM)	FedEx/UPS	\$ 19.95 ea
<b>Hood Pin Kits</b>				
	4033-222-70S	1970-72 Complete Hood Pin Kit (30 pieces) (includes bezels, plates, gaskets, pins, cables, and all hardware to install)	FedEx/UPS	\$ 34.95 kit
<b>Air Cleaner / Cowl Induction Parts</b>				
	4031-230-664S	1968-69 396/350 or 375hp 4-bbl V8 (L34 or L78), also 1968 327/325hp (L79) Open Element Air Cleaner Assembly (base, filter, spark arrestor, and chrome lid) (with silk screened service instructions)	FedEx/UPS	Inquire
	4031-230-664SX	1968-69 396/350 or 375hp 4-bbl V8 (L34 or L78), also 1968 327/325hp (L79) Open Element Air Cleaner Assembly (base, filter, spark arrestor, and chrome lid) (without silk screened service instructions)	FedEx/UPS	\$ 99.95 set
	4031-230-666	1968-69 396/350 or 375hp 4-bbl V8 (L34 or L78), also 1968 327/325hp (L79) Open Element Air Cleaner Base	FedEx/UPS	\$ 44.95 ea

	4031-230-667	1968-69 396/350 or 375hp 4-bbl V8 (L34 or L78), also 1968 327/325hp (L79) Open Element Air Cleaner Chrome Lid (with silk screened service instructions) (can also use for Cowl Induction cars but is not correct)	FedEx/UPS	Inquire
	4031-230-667X	1968-69 396/350 or 375hp 4-bbl V8 (L34 or L78), also 1968 327/325hp (L79) Open Element Air Cleaner Chrome Lid (without silk screened service instructions) (can also use for Cowl Induction cars but is not correct)	FedEx/UPS	\$ 49.95 ea
	4020-230-694S	1970-72 Chevelle / El Camino SS Cowl Induction Air Cleaner Assembly (base, filter, and correct black lid) (without ThermAC flapper in snorkle)	FedEx/UPS	\$ 139.95 set
	4020-230-694SX	1970-72 Chevelle / El Camino SS Cowl Induction Air Cleaner Assembly (base, filter, and chrome lid) (without ThermAC flapper in snorkle)	FedEx/UPS	\$ 159.95 set
	4020-230-6925	1970-72 Chevelle / El Camino SS Cowl Induction Air Cleaner Lid (black)	FedEx/UPS	\$ 29.95 ea
	4033-230-706	1970-72 Chevelle / El Camino SS Cowl Induction Air Cleaner Spacer	FedEx/UPS	\$ 29.95 ea
	4033-230-701	1970-72 Chevelle / El Camino SS Cowl Induction Air Cleaner Flange	FedEx/UPS	\$ 29.95 ea
	4020-230-6912	1970-72 Chevelle / El Camino SS Cowl Induction Air Cleaner Seal	FedEx/UPS	\$ 19.95 ea
	4033-230-702	1970-72 Chevelle / El Camino SS Cowl Induction Flapper Door (hood door)	FedEx/UPS	\$ 49.95 ea
	4033-230-703	1970-72 Chevelle / El Camino SS Cowl Induction Flapper Door Pivot Screw (use 2)	FedEx/UPS	\$ 3.95 ea
	4033-230-703A	1970-72 Chevelle / El Camino SS Cowl Induction Flapper Door Pivot Bushing (use 2)	FedEx/UPS	\$ 3.95 ea
	4033-230-704P	1970-72 Chevelle / El Camino SS Cowl Induction Flapper Door Pivot Brackets (LH / RH pair)	FedEx/UPS	\$ 12.50 pr
	4033-230-704S	1970-72 Chevelle / El Camino SS Cowl Induction Flapper Door Pivot Bracket Hardware Kit	FedEx/UPS	\$ 19.95 kit
	4033-230-7010A	1970-72 Chevelle / El Camino SS Cowl Induction Flapper Door Vacuum Actuator	FedEx/UPS	\$ 29.95 ea
	4033-230-7010	1970-72 Chevelle / El Camino SS Cowl Induction Flapper Door Vacuum Actuator Bracket	FedEx/UPS	\$ 19.95 ea
	4033-230-7010S	1970-72 Chevelle / El Camino SS Cowl Induction Flapper Door Vacuum Actuator Bracket Hardware Kit	FedEx/UPS	\$ 14.95 kit
	4033-230-7011	1970-72 Chevelle / El Camino SS Cowl Induction Flapper Door Vacuum Actuator Flow Control Valve	FedEx/UPS	\$ 19.95 ea
	4020-230-6913	1970-72 Chevelle / El Camino SS Cowl Induction Flapper Valve Frame (actually a Camaro part, but can be used on Chevelle)	FedEx/UPS	\$ 27.50 ea
	4020-230-6913S	1970-72 Chevelle / El Camino SS Cowl Induction Flapper Valve Frame Screw Kit (6 pieces)	FedEx/UPS	\$ 7.50 kit
	4020-230-6914	1970-72 Chevelle / El Camino SS Cowl Induction Flapper Valve	FedEx/UPS	\$ 12.50 ea

	4020-257-67	1970-72 Chevelle / El Camino SS Cowl Induction Flapper Valve Frame Seal (use 1 pair per car)	FedEx/UPS	\$ 5.95 pr
	4020-230-6916S	1970-72 Chevelle / El Camino SS Cowl Induction Flapper Valve Retainers (set of 3)	FedEx/UPS	\$ 3.95 set
	4020-230-6915	1970-72 Chevelle / El Camino SS Cowl Induction Flapper Valve Solenoid	FedEx/UPS	\$ 49.95 ea
	4020-230-6915S	1970-72 Chevelle / El Camino SS Cowl Induction Flapper Valve Solenoid Bolt Kit	FedEx/UPS	\$ 3.95 kit
	4033-230-7012S	1970-72 Chevelle / El Camino SS Hood Screen Hardware Kit	FedEx/UPS	\$ 7.50 kit
	4020-230-6917	1970-72 Chevelle / El Camino SS Cowl Induction Hood Solenoid Wiring Grommet	FedEx/UPS	\$ 7.95 ea
	4033-230-7010S	1970-72 Chevelle / El Camino SS Cowl Induction Hood Actuator Bracket Hardware Kit	FedEx/UPS	\$ 14.95 kit
	4033-230-7011	1970-72 Chevelle / El Camino SS Cowl Induction Hood Air Flow Control Valve	FedEx/UPS	\$ 29.95 ea
	4033-230-7012	1970-72 Chevelle / El Camino SS or Cowl Induction Hood Screen Assembly	FedEx/UPS	\$ 29.95 ea
	4033-230-7012S	1970-72 Chevelle / El Camino SS or Cowl Induction Hood Screen Assembly Hardware Kit	FedEx/UPS	\$ 7.50 kit
	4033-230-7013S	1970-72 Chevelle / El Camino SS Cowl Induction Hood Wire Harness	FedEx/UPS	\$ 34.95 ea
	4020-230-6924	1970-72 Chevelle / El Camino SS Cowl Induction Wire Harness Strap	FedEx/UPS	\$ 6.95 ea
	4020-230-6918	1970-72 Chevelle / El Camino SS Cowl Induction Hood Solenoid Relay	FedEx/UPS	\$ 24.95 ea
	4033-230-709S	1970-72 Chevelle / El Camino SS Cowl Induction Hood Solenoid Relay Screw Kit	FedEx/UPS	\$ 3.95 kit
	4033-230-705	1970-72 Chevelle / El Camino SS Cowl Induction Switch (bolts to gas pedal bracket)	FedEx/UPS	\$ 24.95 ea
	4033-230-705S	1970-72 Chevelle / El Camino SS Cowl Induction Switch Screw Kit	FedEx/UPS	\$ 3.95 kit
	4031-230-665	1968-72 Air Cleaner Flame Arrestor (mesh cap)	FedEx/UPS	\$ 7.95 ea
	4020-230-6922	1969-72 Air Cleaner Connector (valve cover elbow) (small-block V8)	FedEx/UPS	\$ 9.95 ea
	4020-230-6923	1968-72 Air Cleaner Connector (valve cover elbow) (big-block V8)	FedEx/UPS	\$ 14.95 ea
	4011-230-662	1968-70 4-bbl V8 Choke Coil Cover	FedEx/UPS	\$ 5.95 ea
	4020-230-6920S	1970-72 Air Cleaner Stud / Wing Nut Kit (350 4-bbl or 396/454 4-bbl with Rochester 4-bbl) (3.5" long with chrome wing nut) (without Cowl Induction)	FedEx/UPS	\$ 14.95 kit
	4020-230-6921S	1970 SS Air Cleaner Stud / Wing Nut Kit (396/375hp or 454/450hp) (1.62" long with chrome wing nut) (without Cowl Induction)	FedEx/UPS	\$ 14.95 kit
	4033-230-707S	1970 SS Air Cleaner Stud / Wing Nut Kit (396/350hp or 454/360hp) (with Cowl Induction)	FedEx/UPS	\$ 14.95 kit
	4033-230-708S	1970 SS Air Cleaner Stud / Wing Nut Kit (396/375hp or 454/450hp) (with Cowl Induction)	FedEx/UPS	\$ 14.95 kit
	4033-230-711S	1971-72 SS Air Cleaner Stud / Wing Nut Kit (with Cowl Induction)	FedEx/UPS	\$ 14.95 kit

<b>Throttle Cable Brackets</b>				
	4032-233-693	1969-70 4-bbl V8 (exc. SHP)	FedEx/UPS	\$ 24.95 ea
	4033-233-702	1970 396/375hp or 454/450hpV8 (SHP)	FedEx/UPS	\$ 39.95 ea
<b>Windshield Wiper Parts</b>				
	4010-242-621	1968-69 Windshield Washer Reservoir (white)	FedEx/UPS	\$ 7.50 ea
	4010-242-622	1968-69 Windshield Washer Reservoir Bracket	FedEx/UPS	\$ 12.50 ea
	4012-242-711	1971-72 Windshield Washer Reservoir (white)	FedEx/UPS	\$ 24.95 ea
	4010-242-623	1968-72 Windshield Washer Reservoir Cap	FedEx/UPS	\$ 3.50 ea
	4032-242-681P	1968-69 Windshield Washer Nozzles (pair)	FedEx/UPS	\$ 34.95 pr
	4033-242-702P	1970-72 Chevelle / El Camino SS Windshield Washer Nozzles (pair)	FedEx/UPS	\$ 34.95 pr
	4012-242-683	1968-72 Windshield Wiper Blade (use 2 per car)	FedEx/UPS	\$ 9.95 ea
<b>Rear Hood Edge Molding</b>				
	4032-250-68	1968-72 Chevelle / El Camino (except 1970-72 SS)	FedEx/UPS	\$ 39.95 ea
	4032-250-69S	1968-69 Chevelle / El Camino Steel 2" Cowl Induction Hood Rear Edge Molding Set (2-pieces)	FedEx/UPS	\$ 49.95 set
	4033-250-701	1970-72 Heavy Chevy / Chevelle SS / El Camino SS / Sprint SP models (new GM)	FedEx/UPS	\$ 69.95 ea
<b>Hood Scoop Inserts</b>				
	4032-255-682S	1968-69 SS-396 (2-piece set with hardware). <b>New Tooling!</b>	FedEx/UPS	\$ 129.95 set
<b>Crank Pulleys</b>				
	4044-266-652	1968 396 V8 Crank Pulley (for adding power steering)	FedEx/UPS	\$ 49.95 ea
	4012-266-696	1969-70 396/375hp or 454/450hp V8 Crank Pulley (deep groove) (2 groove)	FedEx/UPS	\$ 79.95 ea
<b>Water Pump Pulleys</b>				
	4043-269-641	1968 327 L79 or 396/375hp V8 Deep-Groove Water Pump Pulley	FedEx/UPS	Inquire
	4012-269-693	1969-70 396/375hp Deep Groove Water Pump Pulley	FedEx/UPS	\$ 39.95 ea
<b>Alternator Brackets</b>				
	4031-285-663	1968 396 V8 Lower Alternator Bracket	FedEx/UPS	\$ 59.95 ea
	4012-285-691S	1969-70 small-block V8 Alternator Bracket Set (7-pieces)	FedEx/UPS	\$ 59.95 set
	4012-285-692S	1969-72 big-block V8 Alternator Bracket Set (9-pieces)	FedEx/UPS	\$ 69.95 set
	4012-285-693	1969-70 small-block V8 Upper Alternator Bracket	FedEx/UPS	\$ 49.95 ea
	4012-285-694	1969-72 small-block V8 Lower Alternator Bracket	FedEx/UPS	\$ 14.95 ea
	4012-285-695S	1969-71 small-block V8 Rear Alternator Brace and Spacer	FedEx/UPS	\$ 19.95 set
	4012-285-696S	1969-72 small-block V8 Alternator Mounting Bolt Set	FedEx/UPS	\$ 9.95 set

	4012-285-697P	1969-72 big-block V8 Alternator Brackets (pair)	FedEx/UPS	\$ 59.95 pr
	4012-285-698S	1969-72 big-block V8 Rear Alternator Brace and Spacer	FedEx/UPS	\$ 19.95 set
	4012-285-699S	1969-72 big-block V8 Alternator Mounting Bolt Set (5-pieces)	FedEx/UPS	\$ 14.95 set
<b>Alternator Pulleys</b>				
	4020-286-681	1968-70 327/325hp or 396/375hp or 454/450hp Deep Groove Alternator Pulley	FedEx/UPS	\$ 34.95 ea
<b>Power Steering Pulleys</b>				
	4044-288-655	1968-72 all V8 (except A/C or SHP) Power Steering Pump Pulley	FedEx/UPS	\$ 39.95 ea
	4012-288-693	1969-70 396/375hp or 454/450hp Deep Groove Power Steering Pulley	FedEx/UPS	\$ 39.95 ea
<b>Power Steering Parts</b>				
	4032-289-681	1968 396 V8 Power Steering Reservoir	FedEx/UPS	\$ 49.95 ea
	4031-289-672	1968 396 V8 Power Steering Reservoir Bracket	FedEx/UPS	\$ 24.95 ea
	4012-289-692S	1969-72 small-block V8 Power Steering Pump Bracket Set (3-pieces)	FedEx/UPS	\$ 79.95 set
	4012-289-693S	1969 big-block V8 Power Steering Pump Bracket Set (4-pieces)	FedEx/UPS	\$ 69.95 set
	4012-289-694	1969-72 small-block V8 Power Steering Pump Cradle	FedEx/UPS	\$ 39.95 ea
	4012-289-695	1969-72 small-block V8 Power Steering Rear Bracket	FedEx/UPS	\$ 39.95 ea
	4012-289-696	1969-72 small-block V8 Power Steering Pump Side Bracket ("S"-shaped)	FedEx/UPS	\$ 29.95 ea
	4012-289-699	1969 big-block V8 Power Steering Pump Rear Support Bracket	FedEx/UPS	\$ 24.95 ea
<b>Power Brake Booster Check Valve</b>				
	4010-297-62	1968-72 Check Valve with Grommet	FedEx/UPS	\$ 8.95 ea
<b>Battery Trays</b>				
	4032-300-68	1968-72	FedEx/UPS	\$ 14.95 ea
<b>Battery Tray Hardware</b>				
	4031-301-66S	1968-72 Hold Down Bracket and Bolt Set	FedEx/UPS	\$ 4.95 set
<b>Battery Cable Clips</b>				
	4020-302-671	1968-72 (use as required)	FedEx/UPS	\$ 17.50 ea
<b>Fan Shrouds</b>				
	4032-310-681	1968 small-block V8	FedEx/UPS	\$ 99.95 ea
	4032-310-682	1968 big-block V8	FedEx/UPS	\$ 89.95 ea
	4032-310-69	1969-70 Chevelle / El Camino, 1970-72 Monte Carlo small-block V8 (without A/C or HD Cooling)	FedEx/UPS	\$ 54.95 ea
	4032-310-691	1969-70 Chevelle / El Camino, 1970-72 Monte Carlo small-block V8 (with A/C or HD Cooling)	FedEx/UPS	\$ 89.95 ea
	4032-310-692	1969-70 Chevelle / El Camino, 1970-72 Monte Carlo big-block V8	FedEx/UPS	\$ 59.95 ea
	4033-310-711S	1971-72 Chevelle / El Camino small-block V8 (with A/C or HD Cooling)	FedEx/UPS	\$ 89.95 ea

	4033-310-712S	1971-72 Chevelle / El Camino big-block V8 (without A/C or HD Cooling) (upper and lower 2-piece set)	FedEx/UPS	\$ 119.95 set
	4033-310-713S	1971-72 Chevelle / El Camino big-block V8 (with A/C or HD Cooling) (upper and lower 2-piece set)	FedEx/UPS	\$ 119.95 set
<b>Radiator Support</b>				
	4032-320-68	1968-69	FedEx/UPS	\$ 169.95 ea
	4033-320-70	1970	FedEx/UPS	\$ 169.95 ea
	4033-320-71	1971-72	FedEx/UPS	\$ 169.95 ea
<b>Radiator Mount Cushions</b>				
	4012-326-73	1968-72 with small-block Chevy V8 (use 4 per car) (used between radiator and core support)	FedEx/UPS	\$ 4.95 ea
	4021-326-72	1968-72 with big-block Chevy V8 (use 4 per car) (used between radiator and core support)	FedEx/UPS	\$ 4.95 ea
	4032-326-68S	1968-72 Radiator Support Mounting Cushion Set	FedEx/UPS	\$ 19.95 set
	4032-326-682S	1968-72 Radiator Support Mounting Cushion Hardware Set	FedEx/UPS	\$ 19.95 set
<b>Engine Mount Brackets</b>				
	4032-335-68L / R	1968-72 (except L6 or 307 V8) LH / RH	FedEx/UPS	\$ 34.95 ea
<b>Inner Fenders</b>				
	4032-350-68L / R	1968-72 LH / RH (steel)	FedEx/UPS	\$ 99.95 ea
	4032-350-681P	1969-72 LH / RH pair (plastic) (with control arm seals attached)	FedEx/UPS	\$ 199.95 pr
<b>Vent Cable Assemblies</b>				
	4031-367-673	1968 LH or RH (with chrome knob)	FedEx/UPS	\$ 34.95 ea
	4031-367-674P	1968 Vent Knobs, LH / RH pair (chrome)	FedEx/UPS	\$ 19.95 pr
	4032-367-693	1969-72 LH or RH (with chrome knob) (12" with "round loop" end)	FedEx/UPS	\$ 34.95 ea
	4032-367-694	1969-72 LH or RH (with chrome knob) (14" with "Z" end)	FedEx/UPS	\$ 34.95 ea
	4032-367-695S	1969-72 Vent Knobs, Box of 12	FedEx/UPS	\$ 29.95 box
<b>Steering Column Coupler Repair Kits</b>				
	4030-373-641S	1968-72	FedEx/UPS	\$ 14.95 kit
<b>Firewall Plugs and Seals</b>				
	4030-374-641S	1968-72 Heater Block-Off Plate Set (for models with heater delete)	FedEx/UPS	\$ 179.95 set
<b>Heater Core / Blower Motor Case</b>				
	4030-379-641	1968-72 (without A/C)	FedEx/UPS	\$ 49.95 ea
<b>Cowl Screen Set</b>				
	4032-386-681S	1968-72 (without A/C) (3-piece set)	FedEx/UPS	\$ 24.95 set
	4032-386-682S	1968-72 (with A/C) (3-piece set)	FedEx/UPS	\$ 24.95 set
<b>Door Shells</b>				
	4033-400-70L / R	1970-72 Chevelle 2-door Hardtop / Convertible LH / RH	Truck	\$ 349.95 ea
<b>Front Door Hinges</b>				
	4032-401-681	1968-72 Upper (use 2 per car)	FedEx/UPS	\$ 54.95 ea
	4032-401-682L / R	1968-72 Lower LH / RH	FedEx/UPS	\$ 59.95 ea

<b>Door Hinge Repair Kits</b>				
	4046-402-69S	1968-72 (set of bushings and pins for front hinges)	FedEx/UPS	\$ 14.95 set
	4012-402-68S	1968-72 Hinge Bolt Set	FedEx/UPS	\$ 19.95 set
<b>Outside Rear View Mirrors (non-remote)</b>				
	4011-410-67	1968 (without "Bowtie") LH = RH (mounting kit included)	FedEx/UPS	\$ 29.95 ea
	4020-410-68L / R	1969 all, 1970-72 Wagon / El Camino / Sprint, LH / RH (mounting kit included)	FedEx/UPS	\$ 29.95 ea
	4033-410-70	1970-72 (except Wagon / El Camino), LH = RH (mounting kit included)	FedEx/UPS	\$ 29.95 ea
	4011-410-661S	1968-72 Mirror Mounting Kit (includes bracket, gasket, and hardware) (except 4033-410-70 mirror)	FedEx/UPS	\$ 6.95 set
<b>Vent Window Crank Handles - includes retaining clips</b>				
	4032-419-68	1968 with black knob (paint to match other interior colors)	FedEx/UPS	Inquire
	4032-419-69	1969-72 with clear knob	FedEx/UPS	Inquire
<b>Door Window Regulators</b>				
	4033-420-70L / R	1970-72 2-door Hardtop / Convertible with manual windows, LH / RH	FedEx/UPS	\$ 89.95 ea
<b>Door / Quarter Window Crank Handles - includes retaining clips</b>				
	4012-421-68	1968 with black knob (paint to match other interior colors)	FedEx/UPS	Inquire
	4143-421-69	1968 with black knob (paint to match other interior colors) <i>NOTE: The knob is incorrect for 1968, but is the closest replacement available</i>	FedEx/UPS	\$ 4.95 ea
	4012-421-69	1969-72 with clear knob	FedEx/UPS	\$ 4.95 ea
<b>Door Opening Weatherstrips</b>				
	4032-425-681P	1968-69 2-door Sedan	FedEx/UPS	\$ 69.95 pr
	4032-425-682P	1968 2-door Hardtop / Convertible	FedEx/UPS	\$ 69.95 pr
	4082-425-68P	1968-72 El Camino / Sprint	FedEx/UPS	\$ 69.95 pr
	4032-425-69P	1969-72 2-door Hardtop / Convertible	FedEx/UPS	\$ 69.95 pr
<b>Outside Door Handles</b>				
	4032-440-68LS / RS	1968-69 Front, 1970-72 Wagon / El Camino Front, Handle with Pushbutton Assembly, LH / RH	FedEx/UPS	\$ 29.95 ea
	4033-440-70LS / RS	1970-72 (except Wagon / El Camino) Front, Handle with Pushbutton Assembly, LH / RH	FedEx/UPS	\$ 29.95 ea
<b>Inside Door Handles - includes retaining clips</b>				
	4012-441-68L / R	1968-72 except 1968-69 Chevelle 4-door rear, LH / RH	FedEx/UPS	\$ 14.95 ea
	4143-441-68	1968-69 Chevelle 4-door rear	FedEx/UPS	\$ 11.95 ea
<b>Front Door Latch Assemblies</b>				
	4032-444-68L / R	1968 2-door, LH / RH	FedEx/UPS	\$ 59.95 ea
	4032-444-69L / R	1969-70 2-door, LH / RH	FedEx/UPS	\$ 59.95 ea
	4033-444-71L / R	1971-72 2-door, LH / RH	FedEx/UPS	\$ 59.95 ea
<b>Door Skins</b>				
	4082-450-68L / R	1968-72 El Camino / Sprint LH / RH	FedEx/UPS	\$ 159.95 ea

	4032-450-69L / R	1969 2-door hardtop or convertible LH / RH <i>NOTE: Can be used on 1968 models if inner top rail is discarded.</i>	FedEx/UPS	\$ 159.95 ea
	4033-450-70L / R	1970-72 2-door hardtop or convertible LH / RH	FedEx/UPS	\$ 159.95 ea
<b>Interior Trim Panel Parts</b>				
	4010-453-621S	1968-72 Plastic Interior Trim Panel Mounting Plugs (set of 12) (use as required)	FedEx/UPS	\$ 9.95 set
	4010-453-622	1968-72 Metal Interior Trim Panel Mounting Clip (use as required)	FedEx/UPS	\$ 2.50 ea
<b>Outer Rocker Panels</b>				
	4032-470-68L / R	1968-72 2-door (except El Camino / Sprint) LH / RH	FedEx/UPS	\$ 109.95 ea
<b>Rocker Panel Moldings</b>				
	4033-475-701L / R	1970-72 Malibu 2-door (except SS / El Camino / Sprint) LH / RH (new GM)	FedEx/UPS	\$ 89.95 ea
	4060-475-701P	1970-72 Monte Carlo LH / RH pair	FedEx/UPS	\$ 109.95 pr
<b>Convertible Latch Parts</b>				
	4030-482-641P	1968-72 Latch Hook Knuckles, LH / RH pair	FedEx/UPS	\$ 26.95 pr
	4030-482-642P	1968-72 Latch Hooks, LH / RH pair	FedEx/UPS	\$ 9.95 pr
<b>Door Lock Knobs and Ferrules</b>				
	4012-491-68	1968 Black Knob (use 2-4) (paint to match other interior colors)	FedEx/UPS	\$ 2.95 ea
	4012-491-69	1969-70 Chrome Knob (use 2-4) (with ribbed shaft)	FedEx/UPS	\$ 2.95 ea
	4021-491-70	1971-72 Chrome Knob (use 2-4) (with smooth shaft)	FedEx/UPS	\$ 2.95 ea
	4012-492-68	1968-72 Ferrule (use 2-4)	FedEx/UPS	\$ 2.95 ea
<b>Floor Pans - Best Quality on the market!</b>				
	4032-500-68L / R	1968-72 2-door (except El Camino / Sprint) full-length LH / RH, measure 62" long x 30" wide	Truck	\$ 109.95 ea
	4032-505-68L / R	1968-72 front section, LH / RH, measure 32" long x 30." wide	FedEx/UPS	\$ 59.95 ea
	4032-510-68L / R	1968-72 2-door except El Camino / Sprint rear footwell section, LH / RH, measure 30" long x 30" wide	FedEx/UPS	\$ 54.95 ea
	4032-511-68L / R	1968-72 Under Rear Seat, LH / RH, measures 30" wide x 26" long (each panel comes with seat belt reinforcements welded in place)	FedEx/UPS	\$ 84.95 ea
	4082-511-68	1968-72 El Camino / Sprint Under Bed Storage Box (behind driver's seat)	FedEx/UPS	\$ 119.95 ea
<b>Bucket Seat Mounting Brackets and Console Mounting Brackets</b>				
	4031-507-66S	1968-70 inner and outer mounting brackets (4-piece set) (used to convert bench seats to bucket seats)	FedEx/UPS	\$ 49.95 set
	4033-507-71S	1971-72 inner and outer mounting brackets (4-piece set) (used to convert bench seats to bucket seats)	FedEx/UPS	\$ 49.95 set
	4032-507-681	1968-72 Console Mounting Bracket	FedEx/UPS	\$ 14.95 ea
<b>Shift Boots and Retainers</b>				
	4033-508-701	1968-72 M/T Floor Shift Boot (without console)	FedEx/UPS	\$ 24.95 ea

	4032-508-682S	1968-72 M/T Floor Shift Boot Retainer and Trim Ring Set (without console)	FedEx/UPS	\$ 59.95 set
	4012-508-683S	1968-72 M/T Floor Shift Boot Retainer and Trim Ring Hardware Kit (without console)	FedEx/UPS	\$ 5.95 kit
	4032-508-684	1968-72 M/T Floor Shift Boot (with console)	FedEx/UPS	\$ 24.95 ea
	4032-508-685	1968-72 M/T Floor Shift Boot Retainer (with console)	FedEx/UPS	\$ 24.95 ea
	4032-508-685S	1968-69 Upper Shift Boot Retainer Hardware Kit	FedEx/UPS	\$ 4.95 kit
	4033-508-703S	1970-72 Upper Shift Boot Retainer Hardware Kit	FedEx/UPS	\$ 4.95 kit
<b>Floor Pan Braces</b>				
	4030-517-641	1968-72 Front Brace	FedEx/UPS	\$ 99.95 ea
	4030-517-642	1968-72 Center Brace	FedEx/UPS	\$ 99.95 ea
	4032-517-68	1968-72 Rear Brace	FedEx/UPS	\$ 119.95 ea
<b>Dash Trim and Parts</b>				
	4032-523-691	1969 sedan / El Camino instrument carrier without A/C	FedEx/UPS	\$ 219.95 ea
	4032-523-692	1969 hardtop / convertible instrument carrier without A/C (with correct chrome edging). <b>New tooling!</b>	FedEx/UPS	\$ 219.95 ea
	4032-523-693	1969 instrument carrier with A/C (with correct chrome edging). <b>New tooling!</b>	FedEx/UPS	\$ 219.95 ea
	4032-523-695	1969 Instrument Cluster Lens	FedEx/UPS	\$ 59.95 ea
	4033-523-707	1970-72 (with round gauges) Instrument Cluster Lens	FedEx/UPS	\$ 89.95 ea
	4032-523-684	1968 steering column cover	FedEx/UPS	\$ 39.95 ea
	4032-523-694	1969 steering column cover. <b>New tooling!</b>	FedEx/UPS	\$ 24.95 ea
	4033-523-703	1970-72 (without round gauges) steering column cover	FedEx/UPS	\$ 39.95 ea
	4033-523-704	1970-72 (with round gauges) steering column cover	FedEx/UPS	\$ 39.95 ea
	4032-523-685	1968-72 Lower Steering Column Cover (on floor)	FedEx/UPS	\$ 24.95 ea
	4032-523-689	1968-72 Heater Control Panel Cable "AIR" (without A/C)	FedEx/UPS	\$ 34.95 ea
	4032-523-6810	1968-72 Heater Control Panel Cable "TEMP" (without A/C)	FedEx/UPS	\$ 34.95 ea
	4032-523-6811	1968-72 Heater Control Panel Cable "DEFROST" (without A/C)	FedEx/UPS	\$ 34.95 ea
	4032-523-6812	1968-72 Control Panel Cable "TEMP" (with A/C)	FedEx/UPS	\$ 34.95 ea
	4032-523-6813	1968-72 Control Panel Cable "FAN" (with A/C)	FedEx/UPS	\$ 34.95 ea
	4032-523-6814	1968-72 Control Panel Cable "DEFROST" (with A/C)	FedEx/UPS	\$ 34.95 ea
	4011-523-6710	1968-72 Heat or A/C Control Panel Knob (chrome) (use as required)	FedEx/UPS	\$ 3.50 ea
	4032-523-686R	1968-72 Under Dash Air Door (with A/C)	FedEx/UPS	\$ 34.95 ea
	4032-523-687R	1968-72 Under Dash Air Door Vacuum Pod (with A/C)	FedEx/UPS	\$ 39.95 ea
	4032-523-688	1968-72 Cowl Fresh Air Door Vacuum Pod (with A/C)	FedEx/UPS	\$ 39.95 ea

	4044-523-651	1968-69 Dash Side Astro Vent Balls (use 2 per car)	FedEx/UPS	\$ 21.95 ea
	4044-523-652	1968-69 Dash Side Astro Vent Ball Retainers (use 2 per car)	FedEx/UPS	\$ 5.95 ea
	4044-523-653S	1968-69 Dash Side Astro Vent Ball Seal Kit (4-piece set for both bezels)	FedEx/UPS	\$ 4.95 kit
	4032-523-696S	1969-72 Center Dash Vent Bebuild Kit (2 center vent deflectors, 2 seals, and glue for models with A/C)	FedEx/UPS	\$ 49.95 kit
	4032-523-696	1969-72 Center Dash Deflectors (LH / RH pair for cars with A/C)	FedEx/UPS	\$ 39.95 pr
	4033-523-708	1970 Outer Vent Deflectors (use 2 per car)	FedEx/UPS	\$ 34.95 ea
	4033-523-714	1971-72 Outer Vent Deflectors (use 2 per car)	FedEx/UPS	\$ 34.95 ea
	4033-523-7010P	1970 Outer Vent Deflector Assemblies, LH / RH pair (for models with A/C)	FedEx/UPS	\$ 89.95 pr
	4033-523-716P	1971-72 Outer Vent Deflector Assemblies, LH / RH pair (for models with A/C)	FedEx/UPS	\$ 89.95 pr
	4033-523-7011S	1970 Vent Deflector Kit (7-pieces) (includes center vent deflectors, center vent deflector seals, outer vent deflectors, and glue to rebuild vent deflector assemblies)	FedEx/UPS	\$ 99.95 kit
	4033-523-717S	1971-72 Vent Deflector Kit (7-pieces) (includes center vent deflectors, center vent deflector seals, outer vent deflectors, and glue to rebuild vent deflector assemblies)	FedEx/UPS	\$ 99.95 kit
	4033-523-705R	1970-72 RH Lap Cooler Duct Assembly (models with A/C)	FedEx/UPS	\$ 149.95 ea
	4011-523-672	1968 Light Switch Knob and Rod Assembly	FedEx/UPS	\$ 11.95 ea
	4012-523-691	1969-70 Light Switch Knob and Rod Assembly	FedEx/UPS	\$ 15.95 ea
	4012-523-692	1969-71 Wiper Switch Knob	FedEx/UPS	\$ 6.95 ea
	4010-523-622	1968-69 Lighter Element (Rochester Style)	FedEx/UPS	\$ 9.95 ea
	4010-523-623	1968-69 Lighter Retainer (Rochester Style)	FedEx/UPS	\$ 9.95 ea
	4011-523-675S	1968 Radio Knob Set (for Monaural Radios) (set of 4 knobs)	FedEx/UPS	\$ 19.95 set
	4011-523-676S	1968 Radio Knob Set (for Stereo Radios) (set of 4 knobs)	FedEx/UPS	\$ 19.95 set
	4012-523-697S	1969-70 Radio Knob Set (for Monaural Radios) (set of 4 knobs)	FedEx/UPS	\$ 29.95 set
	4012-523-698S	1969-70 Radio Knob Set (for Stereo Radios) (set of 4 knobs)	FedEx/UPS	\$ 29.95 set
	4011-523-677P	1968 Radio Chrome Knobs (for volume and tuner)	FedEx/UPS	\$ 14.95 pr
	4012-523-699P	1969-70 Radio Chrome / Black Knobs (for volume and tuner)	FedEx/UPS	\$ 16.95 pr
	4011-523-678P	1968 Radio Inner Knobs (for monaural radio)	FedEx/UPS	\$ 11.95 pr
	4012-523-6910P	1969-70 Radio Inner Knobs (for monaural radios)	FedEx/UPS	\$ 12.95 pr
	4012-523-6911P	1969-70 Radio Inner Knobs (for stereo radio)	FedEx/UPS	\$ 12.95 pr
	4011-523-679P	1968-70 Radio Control Shaft Nuts (LH / RH pair) (special thin nuts)	FedEx/UPS	\$ 5.95 pr
	4030-523-643S	1968 Convertible Top Switch Bracket (with mounting clips)	FedEx/UPS	\$ 19.95 ea

<b>Windshield Reveal Molding Set</b>				
	4032-525-68S	1968-72 2-door sedan / hardtop (3-piece set) (lower molding not included)	FedEx/UPS	\$ 99.95 set
<b>Printed Circuit Boards</b>				
	4033-529-7010	1970-72 (with round gauges) (without tachometer)	FedEx/UPS	\$ 104.95 ea
	4033-529-7011	1970-72 (with round gauges) (with tachometer)	FedEx/UPS	\$ 104.95 ea
<b>Dome / Courtesy Lamp Parts</b>				
	4032-531-681	1968-70 Dome Lamp Lens (except Convertible or El Camino) (square)	FedEx/UPS	\$ 5.95 ea
	4032-531-682	1968-70 Dome Lamp Housing (except Convertible or El Camino) (square)	FedEx/UPS	\$ 19.95 ea
	4032-531-683S	1968-70 Dome Lamp Assembly (except Convertible or El Camino) (square) (lens, housing, and wiring)	FedEx/UPS	\$ 34.95 ea
	4010-531-624	1968-72 Convertible Rear Interior Quarter Lamps (use 2 per car)	FedEx/UPS	\$ 5.95 ea
	4082-531-681	1968-72 El Camino / Sprint Dome Lamp Lens	FedEx/UPS	\$ 4.95 ea
	4082-531-69	1969-72 El Camino / Sprint Dome Lamp Housing	FedEx/UPS	\$ 19.95 ea
	4013-531-772	1971-72 (except Convertible / El Camino / Sprint) Dome Lamp Housing (round)	FedEx/UPS	\$ 14.95 ea
<b>Headliner Bow Clips</b>				
	4012-532-681	1968-72 (use 6 per car)	FedEx/UPS	\$ 4.95 ea
<b>Convertible Pillar Post Weatherstrips</b>				
	4032-536-68P	1968 Convertible (pair)	FedEx/UPS	\$ 69.95 pr
	4032-536-69P	1969-72 Convertible (pair)	FedEx/UPS	\$ 69.95 pr
<b>Hardtop Roofrail Weatherstrips</b>				
	4032-537-681P	1968 2-door Hardtop (pair)	FedEx/UPS	\$ 69.95 pr
	4032-537-691P	1969-72 2-door Hardtop (pair)	FedEx/UPS	\$ 69.95 pr
<b>Steering Wheel Parts</b>				
	4030-542-651	1968 Steering Wheel Horn Button Cap Adaptor Bushing	FedEx/UPS	\$ 7.50 ea
	4030-542-641S	1968-72 Steering Wheel Horn Contact / Eyelet / Spring Set	FedEx/UPS	\$ 4.95 set
	4011-542-675S	1968 Woodgrain Steering Wheel Horn Cap Mount Kit (includes horn cap mount cup and contact assembly, hardware, cancel cam, correct wheel mount screw set, pin, spring and retainer)	FedEx/UPS	\$ 29.95 set
	4012-542-693S	1969-70 Woodgrain or Cushion Rim Steering Wheel Horn Cap Mount Kit (includes horn cap mount cup and contact assembly, hardware, cancel cam, correct wheel mount screw set, pin, spring and retainer) (without tilt wheel)	FedEx/UPS	\$ 34.95 set
	4012-542-694S	1969-70 Woodgrain or Cushion Rim Steering Wheel Horn Cap Mount Kit (includes horn cap mount cup and contact assembly, hardware, cancel cam, correct wheel mount screw set, pin, spring and retainer) (with tilt wheel)	FedEx/UPS	\$ 34.95 set

	4031-542-663S	1968-70 Woodgrain or Cushion Rim Steering Wheel Correct Mount Screw Set (6-pieces)	FedEx/UPS	\$ 6.95 set
	4031-542-665	1968-70 Woodgrain or Cushion Rim Steering Wheel Horn Cap Mount Cup and Contact Assembly	FedEx/UPS	\$ 19.95 ea
	4012-542-692	1969 Steering Wheel Hub Ornament "SS"	FedEx/UPS	\$ 9.95 ea
	4012-542-714	1971-72 Sport Steering Wheel Hub Ornament "bowtie" (except Type LT)	FedEx/UPS	\$ 22.50 ea
	4012-542-716	1971-72 Sport Steering Wheel Hub Retainer	FedEx/UPS	\$ 5.95 ea
	4012-542-717	1971-72 Sport Steering Wheel Horn Blowing Contact	FedEx/UPS	\$ 1.95 ea
<b>Turn Signal / Tilt Wheel Lever Parts</b>				
	4012-543-681	1968-70 Turn Signal / Tilt Wheel Lever Knob (Black) (paint to match other interior colors) (without cruise control)	FedEx/UPS	\$ 9.95 ea
	4331-543-673	1971-72 Turn Signal Lever with Knob (Black) (paint to match other interior colors) (with cruise control)	FedEx/UPS	\$ 164.95 ea
	4012-543-713	1971-72 Column Shift Lever Knob (Black) (paint to match other interior colors)	FedEx/UPS	\$ 2.95 ea
<b>Consoles and Parts</b>				
	4032-551-68S	1968 4-speed M/T Console Assembly	FedEx/UPS	\$ 269.95 set
	4032-551-681S	1968 2-speed A/T Console Assembly	FedEx/UPS	\$ 279.95 set
	4032-551-682S	1968 3-speed A/T Console Assembly	FedEx/UPS	\$ 279.95 set
	4032-551-69S	1969 4-speed M/T Console Assembly	FedEx/UPS	\$ 269.95 set
	4032-551-691S	1969 2-speed A/T Console Assembly	FedEx/UPS	\$ 279.95 set
	4032-551-692S	1969 3-speed A/T Console Assembly	FedEx/UPS	\$ 279.95 set
	4033-551-70S	1970-72 Chevelle / El Camino / Sprint 4-speed M/T Console Assembly	FedEx/UPS	\$ 269.95 set
	4033-551-701S	1970 Chevelle / El Camino 2-speed A/T Console Assembly	FedEx/UPS	\$ 279.95 set
	4033-551-702S	1970 Chevelle / El Camino 3-speed A/T Console Assembly	FedEx/UPS	\$ 279.95 set
	4033-551-712S	1971-72 Chevelle / El Camino / Sprint 3-speed A/T Console Assembly	FedEx/UPS	\$ 279.95 set
	4060-551-70S	1970-72 Monte Carlo 4-speed M/T Console Assembly	FedEx/UPS	\$ 269.95 set
	4060-551-701S	1970 Monte Carlo 2-speed A/T Console Assembly	FedEx/UPS	\$ 279.95 set
	4060-551-702S	1970 Monte Carlo 3-speed A/T Console Assembly	FedEx/UPS	\$ 279.95 set
	4060-551-712S	1971-72 Monte Carlo 3-speed A/T Console Assembly	FedEx/UPS	\$ 279.95 set
	4032-551-68AS	1968 Console to Floor Hardware Kit	FedEx/UPS	\$ 5.95 kit
	4032-551-69AS	1969-72 Console to Floor Hardware Kit	FedEx/UPS	\$ 5.95 kit
	4033-551-721	1968-72 Console Base (modify for 1968-71 seat belt buckle retainers)	FedEx/UPS	\$ 169.95 ea
	4032-551-683S	1968-72 Console Base Molding Set (3-pieces)	FedEx/UPS	\$ 24.95 set
	4032-551-683AS	1968-72 Console Base Molding Hardware Kit	FedEx/UPS	\$ 4.95 kit
	4032-551-684	1968 Console Door Assembly	FedEx/UPS	\$ 39.95 ea
	4032-551-684S	1968 Console Door Hardware Kit	FedEx/UPS	\$ 4.95 kit

	4032-551-693S	1969 Console Door Assembly	FedEx/UPS	\$ 39.95 ea
	4032-551-693AS	1969-72 Console Door Hardware Kit	FedEx/UPS	\$ 5.95 kit
	4033-551-703S	1970-72 Console Door Assembly	FedEx/UPS	\$ 39.95 ea
	4031-551-666P	1968 Console Door Bumpers (pair)	FedEx/UPS	\$ 5.95 pr
	4033-551-705S	1970-72 Console Door Latch Hardware Kit	FedEx/UPS	\$ 2.95 kit
	4012-551-682S	1968-69 Console Seat Belt Buckle Retainer Hardware Kit	FedEx/UPS	\$ 12.50 kit
	4046-551-693S	1970-71 Console Seat Belt Buckle Storage Container Hardware Kit	FedEx/UPS	\$ 3.95 kit
	4032-551-689	1968-72 Rear Console Trim Panel / Lamp Assembly	FedEx/UPS	\$ 29.95 set
	4032-551-689S	1968-72 Rear Console Trim Panel / Lamp Assembly Hardware Kit	FedEx/UPS	\$ 4.95 kit
	4032-551-6810	1968-72 Chevelle / El Camino / Sprint M/T Console Top Plate	FedEx/UPS	\$ 64.95 ea
	4060-551-701	1970-72 Monte Carlo M/T Console Top Plate	FedEx/UPS	\$ 64.95 ea
	4032-551-6810S	1968-72 Console Top Plate Hardware Kit	FedEx/UPS	\$ 4.95 kit
	4032-551-6812	1968-72 4-speed M/T Console Top Plate Shift Pattern Emblem	FedEx/UPS	\$ 12.50 ea
	4032-551-6812S	1968-72 4-speed M/T Console Top Plate Shift Pattern Emblem Hardware Kit	FedEx/UPS	\$ 3.95 kit
	4032-551-6813	1968-69 M/T Console Shift Slider Plate	FedEx/UPS	\$ 24.95 ea
	4033-551-708	1970-72 M/T Console Shift Tunnel	FedEx/UPS	\$ 39.95 ea
	4032-551-6814	1968-72 Chevelle / El Camino / Sprint A/T Console Top Plate	FedEx/UPS	\$ 64.95 ea
	4060-551-702	1970-72 Monte Carlo A/T Console Top Plate	FedEx/UPS	\$ 64.95 ea
	4032-551-6815S	1968-72 Chevelle / El Camino / Sprint A/T Console Shifter Plate Assembly	FedEx/UPS	\$ 69.95 set
	4060-551-703S	1970-72 Monte Carlo A/T Console Shifter Plate Assembly	FedEx/UPS	\$ 69.95 set
	4032-551-6815AS	1968-69 A/T Console Shifter Plate Hardware Kit	FedEx/UPS	\$ 5.95 kit
	4033-551-704S	1970-72 A/T Console Shifter Plate Hardware Kit	FedEx/UPS	\$ 5.95 kit
	4032-551-6818S	1968-72 Console A/T Sealing Strips Set (4-pieces)	FedEx/UPS	\$ 5.95 set
	4032-551-6816	1968-70 2-speed A/T Shift Indicator Lens (on Console)	FedEx/UPS	\$ 4.95 ea
	4032-551-6817	1968-70 3-speed A/T Shift Indicator Lens (on Console)	FedEx/UPS	\$ 4.95 ea
	4033-551-712	1971-72 3-speed A/T Shift Indicator Lens (on Console)	FedEx/UPS	\$ 4.95 ea

### Shifter Parts

	4020-552-673S	1968-70 4-speed M/T 2-piece shift knob (black with shift pattern and chrome base) (for Muncie shifter) (without console)	FedEx/UPS	\$ 21.95 ea
	4020-552-681	1968-70 M/T chrome shift knob (for Muncie shifter) (with console)	FedEx/UPS	\$ 22.95 ea
	4032-552-685	1968-72 A/T Shifter Assembly (with console A/T)	FedEx/UPS	\$ 169.95 ea
	4032-552-685S	1968-72 Console A/T Shifter Assembly to Floor Hardware Kit	FedEx/UPS	\$ 4.95 kit
	4020-552-687	1968-72 A/T Shifter Handle Assembly (with console A/T) (included with shifter assembly)	FedEx/UPS	\$ 99.95 set

	4020-552-686	1968-72 A/T Shifter Cable Assembly (with console A/T) (with correct floor grommet)	FedEx/UPS	\$ 44.95 ea
	4020-552-686S	1968-72 A/T Shifter Cable Hardware Kit (with Powerglide or TH-400)	FedEx/UPS	\$ 12.50 kit
	4020-552-693S	1969-72 A/T Shifter Cable Hardware Kit (with TH-350)	FedEx/UPS	\$ 12.50 kit
<b>"Bowtie" Rubber Floor Mats</b>				
	4000-555-67S	1968-72 (4-piece set) Black	FedEx/UPS	\$ 119.95 ea
	4000-555-671S	1968-72 (4-piece set) Red	FedEx/UPS	\$ 119.95 ea
	4000-555-672S	1968-72 (4-piece set) Medium Blue	FedEx/UPS	\$ 119.95 ea
<b>Carpet Sill Plates</b>				
	4032-575-68C	1968-72 2-door, LH = RH (without emblem)	FedEx/UPS	Inquire
	4032-575-681L / R	1968-72 2-door, LH / RH (with emblem) (new GM)	FedEx/UPS	\$ 49.95 ea
	4030-575-644S	1968-72 2-door Carpet Sill Plate Screw Kit (use 2 kits on 4-door models)	FedEx/UPS	\$ 4.95 kit
<b>Fisher Body Sticker</b>				
	4030-576-64	1968-72, (use 2-4 per car)	FedEx/UPS	\$ 1.95 ea
<b>Lug Nuts</b>				
	4000-586-1S	1968-72 all, Box of 50, 7/16-20 (standard lug nuts)	FedEx/UPS	\$ 14.95 box
	4312-586-71	1969-72 SS Sport Wheel, 1971-72 14" x 7" Chevrolet Rally, correct design Stainless Capped	FedEx/UPS	\$ 1.95 ea
<b>Wheel Trim Rings</b>				
	4021-587-781	1968-72 14" x 6" Rally Wheel Trim Ring (use 4) (new GM)	FedEx/UPS	\$ 89.95 ea
	4021-587-782	1969-72 14" x 7" Rally Wheel Trim Ring (use 4) (new GM)	FedEx/UPS	\$ 99.95 ea
	4320-587-692S	1969-70 SS with Sport Wheels Trim Rings (set of 4), (14" x 7")	FedEx/UPS	\$ 99.95 set
	4021-587-70	1971-72 SS Sport Wheel 15" x 7" Trim Ring (use 4) (new GM)	FedEx/UPS	\$ 89.95 ea
<b>Wheel Center Caps</b>				
	4012-588-681	1968-70 Rally Wheel Center Cap Assembly (use 4 per car)	FedEx/UPS	\$ 99.95 ea
	4012-588-682	1968-70 Rally Wheel Center Cap only (Chevrolet Motor Division) (use 4 per car)	FedEx/UPS	\$ 69.95 ea
	4011-588-672	1968-70 Rally Wheel Center Cap Base only (use 4 per car)	FedEx/UPS	\$ 24.95 ea
	4011-588-674S	1968-70 Rally Wheel Center Cap Screw Set (for mounting cap to base) (set of 5 screws)	FedEx/UPS	\$ 7.50 set
	4012-588-691S	1969-70 Chevelle / El Camino SS with Sport Wheel (correct deep center cap, with retainers and screws) (inserts not included) (set of 4)	FedEx/UPS	\$ 74.95 set
	4012-588-692	1969-70 Chevelle / El Camino SS with Sport Wheel "SS" cap Insert (use 4 per car) (new GM)	FedEx/UPS	\$ 16.95 ea
	4531-588-662	1969-70 SS Sport Wheel Center Cap Retainer (use 4) (new GM)	FedEx/UPS	\$ 7.50 ea
	4021-588-702	1971-72 SS Sport Wheel Center Cap (blue bowtie) (use 4) (new GM)	FedEx/UPS	\$ 94.95 ea

<b>Front Disc Brake Backing Plates</b>				
	4011-595-67P	1968 LH / RH pair	FedEx/UPS	\$ 89.95 pr
	4012-595-69P	1969 LH / RH pair	FedEx/UPS	\$ 89.95 pr
	4012-595-70P	1970-72 LH / RH pair	FedEx/UPS	\$ 89.95 pr
	4012-596-691P	1969-72 Caliper Dust Caps, LH / RH pair	FedEx/UPS	\$ 7.95 pr
<b>Quarter Panel Skins</b>				
	4032-600-68L / R	1968 Chevelle 2-door, LH / RH, 33" high x 62" long	Truck	\$ 169.95 ea
	4082-600-68L / R	1968-72 El Camino / Sprint, LH / RH, 29" high x 87" long (cut out side marker holes on 1968-69 models)	Truck	\$ 229.95 ea
	4032-600-69L / R	1969 Chevelle 2-door, LH / RH, 33" high x 62" long	Truck	\$ 169.95 ea
	4033-600-70L / R	1970-72 Chevelle 2-door, LH / RH, 27" high x 77" long	Truck	\$ 209.95 ea
	4033-605-70L / R	1970-72 Chevelle 2-door, LH / RH (21" high x 77" long)	Truck	\$ 149.95 ea
	4060-600-70L / R	1970-72 Monte Carlo, LH / RH (27" high x 77" long)	Truck	\$ 209.95 ea
<b>Factory-Style Quarter Panels</b>				
	4032-601-68L / R	1968 Chevelle 2-door hardtop LH / RH <b>Due Spring / Summer, 2005!</b>	Truck	\$ 509.95 ea
	4032-601-69L / R	1969 Chevelle 2-door hardtop LH / RH <b>Due Spring / Summer, 2005!</b>	Truck	\$ 509.95 ea
	4033-601-70L / R	1970-72 Chevelle 2-door hardtop LH / RH - <b>Made with original GM Tooling!</b>	Truck	\$ 599.95 ea
	4033-601-701L / R	1970-72 Chevelle 2-door hardtop LH / RH (aftermarket) (with full sail panel) <b>New Tooling!</b>	Truck	\$ 479.95 ea
	4033-602-70L / R	1970-72 Chevelle 2-door convertible LH / RH <b>- Made with original GM Tooling!</b>	Truck	\$ 799.95 ea
<b>Door Jamb Striker Peg</b>				
	4030-606-64	1968-72 (use 2-4) (collar included)	FedEx/UPS	\$ 15.95 ea
<b>Door Jamb Vent Louvers</b>				
	4032-612-69P	1969 2-door Hardtop / Convertible (LH / RH pair with correct rubber seals)	FedEx/UPS	\$ 39.95 pr
	4021-612-70P	1970-72 2-door Hardtop / Convertible (LH / RH pair with correct rubber seals)	FedEx/UPS	\$ 49.95 pr
	4021-612-70	1970-72 2-door Hardtop / Convertible (use 2 per car) (new GM)	FedEx/UPS	\$ 32.95 ea
<b>Bed Moldings</b>				
	4082-616-68S	1968-72 El Camino / Sprint Bed Top Molding Kit (10 pieces with clips)	FedEx/UPS	\$ 449.95 kit
	4082-616-681	1968-72 El Camino / Sprint Tailgate Top Molding (with hardware)	FedEx/UPS	\$ 79.95 ea
	4082-616-681S	1968-72 El Camino / Sprint Tailgate Top Molding Hardware Kit	FedEx/UPS	\$ 19.95 kit
	4082-616-682P	1968-72 El Camino / Sprint Rear Corner Extension Moldings, LH / RH pair (from upper corner to tail lamp bezel)	FedEx/UPS	\$ 29.95 pr
	4082-616-683L / R	1968-72 El Camino / Sprint Rear Corner, LH / RH	FedEx/UPS	\$ 49.95 ea
	4082-616-684L / R	1968-72 El Camino / Sprint Bedside Top Rails, LH / RH (with hardware)	FedEx/UPS	\$ 59.95 ea

	4082-616-685L / R	1968-72 El Camino / Sprint Front Corner, LH / RH	FedEx/UPS	\$ 59.95 ea
	4082-616-686	1968-72 El Camino / Sprint Front Bed Molding (with hardware)	FedEx/UPS	\$ 49.95 ea
	4082-616-686S	1968-72 El Camino / Sprint Front Bed Molding Hardware Kit	FedEx/UPS	\$ 19.95 kit
<b>Rear Side Markers</b>				
	4012-625-68	1968-69 Wagon / El Camino (use 2) (red lens)	FedEx/UPS	\$ 7.95 ea
	4012-625-681	1968-69 Wagon / El Camino (use 2) (red lens) (with socket and bulb)	FedEx/UPS	\$ 19.95 ea
	4020-625-69	1969 (except Wagon / El Camino) (use 2) (red lens)	FedEx/UPS	\$ 12.50 ea
	4033-625-70P	1970-72 (except Wagon / El Camino) (LH / RH pair) (red lens)	FedEx/UPS	\$ 59.95 pr
<b>Rear Side Marker Bezels</b>				
	4032-141-69	1969 (except Wagon / El Camino) (use 2)	FedEx/UPS	\$ 24.95 ea
<b>Rear Interior Quarter Trim</b>				
	4033-645-701S	1970-72 2-door Hardtop Interior Trim Panels, LH / RH pair with upper seat side strips (4-piece set), Black	FedEx/UPS	\$ 109.95 set
<b>Rear Interior Quarter Ashtrays and Inserts</b>				
	4012-647-68	1968-69 2-door (except Convertible) Ashtray Assembly (use 2 per car) (with "ribbed" lid)	FedEx/UPS	\$ Inquire
	4012-647-70	1970-72 2-door (except Convertible) Ashtray Assembly (use 2 per car) (with "smooth" lid)	FedEx/UPS	\$ 24.95 ea
	4012-647-681P	1968-72 2-door (except Convertible) Ashtray Inserts only (LH / RH pair)	FedEx/UPS	\$ 14.95 pr
	4020-647-671	1968-69 Convertible Ashtray Assembly (use 2 per car) (with "ribbed" lid)	FedEx/UPS	Inquire
	4033-647-70	1970-72 Convertible Ashtray Assembly (use 2 per car) (with "smooth" lid)	FedEx/UPS	\$ 29.95 ea
	4020-647-671P	1968-72 2-door Convertible Ashtray Inserts only (LH / RH pair)	FedEx/UPS	\$ 14.95 pr
<b>Quarter Glass Weatherstrips</b>				
	4032-664-68P	1968-72 2-door Hardtop / Convertible LH / RH pair (includes steel insert)	FedEx/UPS	\$ 19.95 pr
<b>Quarter Glass Chrome</b>				
	4032-665-68L / R	1968 2-door Hardtop / Convertible LH / RH pair (includes glass insert)	FedEx/UPS	\$ 39.95 ea
	4032-665-69P	1969-72 2-door Hardtop / Convertible LH / RH pair (includes glass insert)	FedEx/UPS	\$ 89.95 pr
<b>Inner Wheelhouse Panels</b>				
	4032-670-68L / R	1968-72 sedan / hardtop LH / RH	FedEx/UPS	\$ 149.95 ea
<b>Outer Wheelhouse Panels</b>				
	4032-675-68L / R	1968-69 except Wagon / Convertible, also 1968-72 El Camino / Sprint, LH / RH	FedEx/UPS	\$ 99.95 ea
	4033-675-70L / R	1970-72 except Wagon / Convertible / El Camino / Sprint, LH / RH	FedEx/UPS	\$ 99.95 ea
<b>Lower Rear Quarter Panel Patches</b>				
	4033-690-70L / R	1970-72 Chevelle 2-door LH / RH (13" high x 32" long)	FedEx/UPS	\$ 39.95 ea

<b>Trunk Lids</b>				
	4032-700-68	1968-72	Truck	\$ 229.95 ea
<b>Trunk Lid Emblems</b>				
	4032-702-69	1969 "Chevelle by Chevrolet" Trunk Lid Emblem (new GM)	Truck	\$ 39.95 ea
<b>Trunk Weatherstrips</b>				
	4030-703-64	1968-72	FedEx/UPS	\$ 19.95 ea
<b>Trunk Lock Cylinder Retainer</b>				
	4032-705-682	1968-72	FedEx/UPS	\$ 14.95 ea
<b>Deck Filler Panels</b>				
	4032-710-68	1968-72 2-door sedan / hardtop	FedEx/UPS	\$ 64.95 ea
<b>Convertible Pinchweld Moldings</b>				
	4032-711-681P	1968 Convertible (LH / RH pair)	FedEx/UPS	\$ 169.95 pr
	4032-711-691P	1969-72 Convertible (LH / RH pair)	FedEx/UPS	\$ 174.95 pr
	4032-711-682	1968-72 Convertible Pinchweld Molding Clip (use as required)	FedEx/UPS	\$ 3.95 ea
<b>Weatherstrip Gutter Sets</b>				
	4032-714-68S	1968-72 LH / RH pair, plus a patch for the front edge of the trunk opening. <b>Currently being tooled!</b>	FedEx/UPS	Inquire
<b>Rear Window Reveal Molding Sets</b>				
	4032-715-68S	1968-72 2-door sedan / hardtop (4-pieces)	FedEx/UPS	\$ 199.95 set
	4082-715-68S	1968-72 El Camino / Sprint (5-pieces)	FedEx/UPS	\$ 199.95 set
<b>Trunk Floors</b>				
	4032-725-68S	1968-72 7-piece set includes LH, RH and center floor sections, 2 floor braces, and 2 body mount braces, measures 62.5" wide x 37" long	FedEx/UPS	\$ 269.95 set
	4032-725-68	1968-72 1-piece floor, measures 56" wide x 34" long (shipped truck freight)	Truck	\$ 119.95 ea
	4032-725-68U	1968-72 1-piece floor, measures 47" wide x 34" long (ships UPS / Fed Ex Ground)	FedEx/UPS	\$ 109.95 ea
<b>Spare Tire / Jack Stowage Brackets</b>				
	4010-726-621	1968-70 Spare Tire Hold-Down Bracket	FedEx/UPS	\$ 5.95 ea
	4021-726-701	1970-72 Spare Tire Hold-Down Bracket	FedEx/UPS	\$ 11.95 ea
	4032-726-681	1968-72 Jack Stowage Bracket	FedEx/UPS	\$ 11.95 ea
	4011-726-671	1968-72 Spare Tire Wing Nut	FedEx/UPS	\$ 6.95 ea
	4021-726-75	1968-72 Spare Tire J-Bolt (5/16-18 x 6) (trim to original size)	FedEx/UPS	\$ 11.95 ea
<b>Trunk Floor Drop-Offs</b>				
	4032-735-68L / R	1968 (except Wagon / El Camino) LH / RH	FedEx/UPS	\$ 59.95 ea
	4032-735-69L / R	1969 (except Wagon / El Camino) LH / RH	FedEx/UPS	\$ 59.95 ea
	4033-735-70L / R	1970-72 (except Wagon / El Camino / Sprint) LH / RH	FedEx/UPS	\$ 59.95 ea
<b>Body Mount Braces - welds under trunk floor</b>				
	4032-740-68L / R	1968-72 (except Wagon / El Camino / Sprint) LH / RH	FedEx/UPS	\$ 34.95 ea
<b>Trunk Floor Braces</b>				
	4032-745-68	1968-72 (except Wagon / El Camino / Sprint) (use 2)	FedEx/UPS	\$ 39.95 ea

<b>Gas Tank Mounting Straps</b>				
	4032-749-68P	1968-72 (except Wagon), LH / RH pair	FedEx/UPS	\$ 29.95 pr
	4032-749-681S	1968-72 (except Wagon) Strap Hardware Set	FedEx/UPS	\$ 9.95 kit
<b>Gas Tanks</b>				
	4032-750-681	1968-69 (except Wagon or El Camino) with filler neck (2 vent pipes)	FedEx/UPS	\$ 209.95 ea
	4033-750-702	1970 Chevelle (except Wagon or El Camino) without EEC, with filler neck (no vent pipe)	FedEx/UPS	\$ 209.95 ea
	4033-750-703	1970-72 (except Wagon / El Camino / Sprint), 1970 Monte Carlo, with EEC, with filler neck (3 vent pipes)	FedEx/UPS	\$ 209.95 ea
	4082-750-681	1968-70 El Camino without EEC w/ filler neck except wagons (no vent pipe)	FedEx/UPS	\$ 209.95 ea
	4083-750-701	1970-72 El Camino / Sprint, w/ filler neck w/ EEC (3 vent pipes)	FedEx/UPS	\$ 209.95 ea
	4060-750-70	1970 Monte Carlo w/ filler neck w/o EEC (no vent pipes)	FedEx/UPS	\$ 209.95 ea
	4060-750-701	1970 Monte Carlo w/ filler neck w/o EEC (2 vent pipes)	FedEx/UPS	\$ 209.95 ea
	4060-750-71	1971-72 Monte Carlo w/ filler neck w/ EEC (3 vent pipes)	FedEx/UPS	\$ 209.95 ea
<b>Gas Caps</b>				
	4030-757-641	1968-69 (except Wagon / El Camino)	FedEx/UPS	\$ 9.95 ea
	4082-757-68	1968-70 Wagon / El Camino (without EEC)	FedEx/UPS	\$ 17.50 ea
	2130-757-621	1970 (except Wagon / El Camino) (without EEC)	FedEx/UPS	\$ 12.50 ea
	4012-757-701	1970 all (with EEC)	FedEx/UPS	\$ 9.95 ea
	4012-757-711	1971-72 all	FedEx/UPS	\$ 12.50 ea
<b>Trunk Lid Moldings</b>				
	4060-775-701	1970-71 Monte Carlo Trunk Lid Molding	FedEx/UPS	\$ 59.95 ea
	4060-775-70P	1970-71 Monte Carlo Outer Trunk Lid Moldings, LH / RH pair	FedEx/UPS	\$ 49.95 pr
<b>Rear Chrome Bumpers</b>				
	4032-800-68	1968 Malibu / SS-396 (except Wagon)	FedEx/UPS	\$ 199.95 ea
	4082-800-68	1968 Wagon / 1968-72 El Camino / Sprint	FedEx/UPS	\$ 199.95 ea
	4032-800-69	1969 (except Wagon / El Camino)	FedEx/UPS	\$ 199.95 ea
	4033-800-70	1970 (except Wagon / El Camino)	FedEx/UPS	\$ 199.95 ea
	4033-800-702	1970 SS Rear Bumper Pad	FedEx/UPS	\$ 129.95 ea
	4033-800-71	1971-72 (except Wagon / El Camino / Sprint)	FedEx/UPS	\$ 199.95 ea
<b>Rear Bumper Bolt Kits - set of bolts, nuts, and washers</b>				
	4032-801-681S	1968 (except Wagon / El Camino) (31 pieces)	FedEx/UPS	\$ 29.95 kit
	4032-801-691S	1969 (except Wagon / El Camino)	FedEx/UPS	\$ 29.95 kit
	4082-801-681S	1968-69 Wagon / El Camino	FedEx/UPS	\$ 29.95 kit
	4033-801-701S	1970-72 Chevelle (except Wagon / El Camino) (28 pieces)	FedEx/UPS	\$ 19.95 kit
	4060-801-701S	1970-72 Monte Carlo	FedEx/UPS	\$ 29.95 kit
	4083-801-701S	1970-72 Wagon / El Camino / Sprint	FedEx/UPS	\$ 29.95 kit

<b>Rear Bumper Bracket Hardware Kits - to mount the brackets to the frame</b>				
	4032-807-681S	1968 (except Wagon / El Camino) (26 pieces)	FedEx/UPS	\$ 39.95 kit
	4032-807-691S	1969 (except Wagon / El Camino)	FedEx/UPS	\$ 29.95 kit
	4082-807-681S	1968-69 Wagon / El Camino	FedEx/UPS	\$ 39.95 kit
	4033-807-701S	1970-72 Chevelle (except Wagon / El Camino) (12 pieces)	FedEx/UPS	\$ 24.95 kit
	4060-807-701S	1970-72 Monte Carlo	FedEx/UPS	\$ 27.50 kit
	4083-807-701S	1970-72 Wagon / El Camino / Sprint	FedEx/UPS	\$ 39.95 kit
<b>Tailgate Moldings</b>				
	4082-822-691	1968-69 El Camino Custom, 1969-72 Concours Wagon, Upper (with hardware)	FedEx/UPS	\$ 49.95 ea
	4082-822-692	1968-69 El Camino Custom, 1969-72 Concours Wagon, Lower (with hardware)	FedEx/UPS	\$ 49.95 ea
	4082-822-693P	1968-69 El Camino Custom Tailgate Extension Moldings, Upper and Lower pair (use 2 pair per car)	FedEx/UPS	\$ 39.95 pr
	4083-822-701	1970-72 El Camino Custom, Upper (with hardware)	FedEx/UPS	\$ 49.95 ea
	4083-822-702	1970-72 El Camino Custom, Lower (with hardware)	FedEx/UPS	\$ 49.95 ea
<b>Tailgate Hardware</b>				
	4082-825-682S	1968-72 El Camino / Sprint / Chevelle Wagon Inner Tailgate Panel Hardware Kit	FedEx/UPS	\$ 12.50 kit
	4082-825-683S	1968-72 El Camino / Sprint Tailgate Cable Kit (cables, bolts, and springs)	FedEx/UPS	\$ 39.95 kit
	HW2476	1968-72 El Camino / Sprint / Chevelle Wagon Tailgate Bumper	FedEx/UPS	\$ 1.95 ea
<b>Tailgate Skins</b>				
	4082-827-68	1968 El Camino	FedEx/UPS	\$ 159.95 ea
	4082-827-69	1969-72 El Camino / Sprint	FedEx/UPS	\$ 159.95 ea
<b>Tail Lamp Bezels</b>				
	4032-840-68P	1968 Malibu / SS-396 (except Wagon / El Camino) LH / RH pair	FedEx/UPS	\$ 149.95 pr
	4032-840-69P	1969 Malibu / SS-396 (except Wagon / El Camino) LH / RH pair	FedEx/UPS	\$ 149.95 pr
<b>Tail Lamp Lenses</b>				
	4032-845-69P	1969 Chevelle (except Wagon), LH / RH pair	FedEx/UPS	\$ 69.95 pr
	4033-845-702L / R	1970 Malibu / SS (except Wagon / El Camino) Tail Lamp Lens, LH / RH (new GM)	FedEx/UPS	\$ 49.95 ea
<b>Back-Up Lamp Assemblies</b>				
	4032-846-681S	1968 Malibu / SS-396 (except Wagon / El Camino) (use 2 per car)	FedEx/UPS	\$ 39.95 ea
	4082-846-691S	1969-72 Wagon / El Camino (use 2 per car)	FedEx/UPS	\$ 59.95 ea
	4082-846-692P	1969-72 Wagon / El Camino Bumper Reflector Assemblies (LH / RH pair)	FedEx/UPS	\$ 44.95 pr
<b>Back-Up Lamp Lenses</b>				
	4082-847-691	1969-72 Wagon / El Camino (use 2 per truck)	FedEx/UPS	\$ 24.95 ea
<b>Tail Panels</b>				
	4032-850-68	1968 (except Wagon / El Camino) <b>Now in Stock!</b>	FedEx/UPS	\$ 249.95 ea

	4032-850-69	1969 (except Wagon / El Camino) <b>Now in Stock!</b>	FedEx/UPS	\$ 249.95 ea
	4033-850-70	1970-72 (except Wagon / El Camino) <b>Now in Stock!</b>	FedEx/UPS	\$ 209.95 ea
<b>Tail Panel Moldings</b>				
	4032-855-681	1968 Malibu / SS-396 (except Wagon / El Camino), Upper Molding (with hardware)	FedEx/UPS	\$ 49.95 ea
	4032-855-682	1968 Malibu / SS-396 (except Wagon / El Camino), Lower Molding (with hardware)	FedEx/UPS	\$ 49.95 ea
	4032-855-691	1969 Malibu / SS-396 (except Wagon / El Camino), Upper Molding (with hardware)	FedEx/UPS	\$ 49.95 ea
	4032-855-692	1969 Malibu / SS-396 (except Wagon / El Camino), Lower Molding (with hardware)	FedEx/UPS	\$ 49.95 ea
<b>Rear Axle Cover</b>				
	4044-860-652	1968-72 12-bolt Rear Axle Cover	FedEx/UPS	\$ 49.95 ea
<b>Rear Valance Panels</b>				
	4033-875-70	1970 (except Wagon / El Camino)	FedEx/UPS	\$ 74.95 ea
	4033-875-71	1971-72 (except Wagon / El Camino)	FedEx/UPS	\$ 79.95 ea
<b>Chrome Exhaust Tips</b>				
	4032-881-69P	1969-72 SS models (pair) <i>NOTE: This is cosmetically different from some early 1969 models which had a "rolled" edge.</i>	FedEx/UPS	\$ 59.95 pr
<b>Rear License Plate Bracket / Gas Filler Door</b>				
	4012-885-68	1968-72 (exc. Wagon / El Camino)	FedEx/UPS	\$ 44.95 ea
<b>License Lamp Assembly</b>				
	4011-886-66	1968 (except Wagon / El Camino)	FedEx/UPS	\$ 19.95 ea
	4081-886-66	1968-72 Wagon / El Camino, 1970-72 Chevelle / Monte Carlo	FedEx/UPS	\$ 34.95 ea
<b>License Lamp Lens</b>				
	4011-887-66	1968-70 (except Wagon / El Camino / Monte Carlo)	FedEx/UPS	\$ 7.95 ea
<b>Side Marker Sets</b>				
	4032-905-691S	1969 L6 or SS-396 models (except Wagon / El Camino) (set of 4 markers plus bezels)	FedEx/UPS	\$ 124.95 set
	4032-905-692S	1969 307 / 350 V8 models (except Wagon / El Camino) (set of 4 markers plus rear bezels only)	FedEx/UPS	\$ 99.95 set
	4033-905-70S	1970 (set of 4 markers only)	FedEx/UPS	\$ 99.95 set
<b>Body Side Molding Sets</b>				
	4032-909-681S	1968 Malibu 2-door (6-piece set)	FedEx/UPS	\$ 209.95 set
	4032-909-682S	1968 SS-396 2-door (8-piece set)	FedEx/UPS	\$ 274.95 set
	4082-909-68S	1968 El Camino Custom 2-door (8-piece set)	FedEx/UPS	\$ 274.95 set
	4032-909-69S	1969 Malibu 2-door (8-piece set)	FedEx/UPS	\$ 274.95 set
	4082-909-69S	1969 El Camino Custom 2-door (8-piece set)	FedEx/UPS	\$ 274.95 set
	4083-909-70S	1970-72 El Camino Custom 2-door (10-piece set)	FedEx/UPS	\$ 299.95 set
<b>Gas Pedal Pads and Parts</b>				
	4012-911-681	1968-72 Gas Pedal Pad	FedEx/UPS	\$ 6.95 ea
	4012-911-683	1968-72 Gas Pedal Pad Mounting Pin	FedEx/UPS	\$ 2.95 ea
	4012-911-684	1968-72 Gas Pedal Pad Tension Spring	FedEx/UPS	\$ 4.95 ea

<b>M/T Clutch / Brake Pedal Pads and Trim</b>				
	4030-912-64	1968-72 Clutch / Brake Pedal Pad (except 1968-71 Disc Brake) (use 1 or 2 per car)	FedEx/UPS	\$ 5.95 ea
	4032-912-68	1968-71 M/T Disc Brake Pedal Pad	FedEx/UPS	\$ 9.95 ea
<b>A/T Brake Pedal Pads and Trim</b>				
	4030-913-64	1968-72 A/T Brake Pedal Pad (except 1968-71 Disc Brake Pad)	FedEx/UPS	\$ 8.95 ea
	4032-913-68	1968-71 A/T Disc Brake Pedal Pad	FedEx/UPS	\$ 12.50 ea
<b>Park Brake Pedal Pads and Trim</b>				
	4020-914-671	1968-72 Park Brake Pedal Pad	FedEx/UPS	\$ 4.95 ea
	4020-914-673	1968-72 Park Brake Frame Guide Bar	FedEx/UPS	\$ 7.95 ea
<b>Clutch / Brake Pedal Parts</b>				
	4032-915-681S	1968-72 Clutch / Brake Pedal Assembly (with bushings and pin clip)	FedEx/UPS	\$ 89.95 set
	4032-915-691S	1969-72 4-speed Reverse Lock-Out Linkage Assembly	FedEx/UPS	\$ 89.95 set
	4010-915-621	1968-72 Brake / Clutch Pedal Bushing (use as required)	FedEx/UPS	\$ 1.25 ea
	HW2411	1968-72 Stoplight Switch Clip (use 1 per car)	FedEx/UPS	\$ 1.25 ea
	HW2415	1968-72 Brake Pedal Clevis Pin Retainer (use 1 per car)	FedEx/UPS	\$ 1.95 ea
	HW2417	1968-72 Clutch / Brake Pedal Shaft Retainer (use 1 per car)	FedEx/UPS	\$ 1.25 ea
<b>Powerglide Kickdown Upper Linkage Rods</b>				
	4011-916-671S	1968-72 2-bbl V8 (with swivel)	FedEx/UPS	\$ 29.95 set
	4011-916-672S	1968-70 4-bbl V8 (with swivel)	FedEx/UPS	\$ 29.95 set
<b>Bucket Seat Back Release Button and Headrest Escutcheons</b>				
	4011-921-66	1968 Strato-Bucket Seats (on side) (use 2)	FedEx/UPS	\$ 34.95 ea
	4012-921-691	1969-72 Bucket Seat Back Release Button (use 2 per car)	FedEx/UPS	\$ 29.95 ea
	4012-921-692P	1969 Bucket Seat Headrest Escutcheons, pair for one seat	FedEx/UPS	\$ 34.95 pr
	4012-921-701P	1970-72 Bucket Seat Headrest Escutcheons, pair for one seat	FedEx/UPS	\$ 34.95 pr
<b>Bucket Seat Trim</b>				
	4012-922-683S	1968 Plastic Bucket Seat Back and Side Panel Trim (6-piece set), Black (with chrome trim and bullets)	FedEx/UPS	\$ 129.95 set
	4012-922-693S	1969-72 Plastic Bucket Seat Back and Side Panel Trim (6-piece set), Black (with chrome trim)	FedEx/UPS	\$ 129.95 set
	4011-922-662	1968-72 Bucket Seat Back Bumper (use 4 per car)	FedEx/UPS	\$ 4.95 ea
	4011-922-671P	1968-72 Bench Seat Hinge Covers, LH / RH pair (Black)	FedEx/UPS	\$ 49.95 pr
<b>Interior Armrest Bases</b>				
	4020-923-68L / R	1968-72 Front Black LH / RH	FedEx/UPS	\$ 29.95 ea
	4020-923-681L / R	1969 Front Parchment LH / RH	FedEx/UPS	\$ 29.95 ea
	4020-923-682L / R	1968-69 Front Red LH / RH	FedEx/UPS	\$ 29.95 ea
	4020-923-683L / R	1970 Front Bright Blue LH / RH	FedEx/UPS	\$ 29.95 ea
	4020-923-684L / R	1969-70 & 1972 Front Dark Green LH / RH	FedEx/UPS	\$ 29.95 ea
	4020-923-685L / R	1972 Front White LH / RH	FedEx/UPS	\$ 29.95 ea

	4020-923-686L / R	1968 Front Medium Blue LH / RH	FedEx/UPS	\$ 29.95 ea
	4020-923-687L / R	1969 Front Dark Blue LH / RH	FedEx/UPS	\$ 29.95 ea
	4020-923-688L / R	1968 Front Ivy Gold LH / RH	FedEx/UPS	\$ 29.95 ea
	4020-923-689L / R	1968 & 1970 Front Pearl LH / RH	FedEx/UPS	\$ 29.95 ea
	4012-923-68S	1968-72 Armrest Base Screw Set (set of 6 screws for both sides)	FedEx/UPS	\$ 6.95 set
<b>Drip Rail Molding Sets</b>				
	4032-925-68S	1968-69 2-door sedan / hardtop (6-piece set)	FedEx/UPS	\$ 119.95 set
	4082-925-68S	1968-72 El Camino (6-piece set)	FedEx/UPS	\$ 119.95 set
	4033-925-70S	1970-72 Chevelle 2-door hardtop (6-piece set)	FedEx/UPS	\$ 119.95 set
<b>Seat Belt Parts</b>				
	4012-926-69S	1968-72 Shoulder Belt Retainer / Cover Set (8 pieces)	FedEx/UPS	\$ 16.95 set
	4012-926-682S	1968-72 Shoulder Belt Retainer / Cover Hardware Kit	FedEx/UPS	\$ 7.95 kit
	4011-926-671	1968-71 Outer Front Bolt (use 2)	FedEx/UPS	\$ 12.50 ea
	4011-926-672	1968-71 Front Lap / Shoulder Inner Bolt (use 2)	FedEx/UPS	\$ 12.50 ea
	4011-926-673	1968-71 Rear Inner / Outer Bolt (use 4)	FedEx/UPS	\$ 12.50 ea
<b>Vinyl Top / 2-Tone Paint Moldings</b>				
	4032-927-682P	1968-69 Chevelle 2-door Rear LH / RH pair	FedEx/UPS	\$ 79.95 pr
	4082-927-681P	1968-72 El Camino / Sprint LH / RH pair	FedEx/UPS	\$ 89.95 pr
	4033-927-701P	1970-72 Chevelle 2-door Front LH / RH pair	FedEx/UPS	\$ 39.95 pr
	4033-927-703P	1970-72 Chevelle 2-door Rear LH / RH pair	FedEx/UPS	\$ 79.95 pr
<b>Spark Plug Wire Shields</b>				
	4031-930-661S	1968-71 big block V8 Spark Plug Wire Shield Set	FedEx/UPS	\$ 49.95 set
<b>Inside Rear View Mirror</b>				
	4032-935-691	1969-72 (without map lamp) <i>NOTE: The stainless back has to be painted black for street use to cut down on glare to oncoming cars.</i>	FedEx/UPS	\$ 49.95 ea
<b>Sunvisor Support Brackets and Hardware</b>				
	4030-941-641	1968-72 (except Convertible) Sunvisor Support Bracket (use 2 per car)	FedEx/UPS	\$ 29.95 ea
	4030-941-643S	1968-72 Coupe Sunvisor Support Screw Set (use 2 per car) (set of 4 pieces)	FedEx/UPS	\$ 2.95 set
	4030-941-644	1968-72 Sunvisor Support Bushing (use 2 per car)	FedEx/UPS	\$ 1.95 ea
	4032-941-681P	1968-72 (except Convertible) Sunvisor Support Bracket (LH / RH pair)	FedEx/UPS	\$ 99.95 pr
	4030-941-645	1968-72 Convertible Sunvisor Post Rubber Tip (use 2 per car)	FedEx/UPS	\$ 2.95 ea
<b>Wheel Opening Moldings (4-piece sets)</b>				
	4032-950-69S	1969 Chevelle SS-396 / El Camino SS-396	FedEx/UPS	Inquire
	4030-950-651S	1968-69 Wheel Opening Molding Screw Kit (32 pieces)	FedEx/UPS	\$ 9.95 kit
	4033-950-70S	1970-72 Malibu or SS (except wagon or El Camino)	FedEx/UPS	Inquire
	4010-950-651S	1970-72 Wheel Opening Molding Screw Kit (28 pieces)	FedEx/UPS	\$ 9.95 kit

<b>Clutch Linkage Parts</b>				
	4032-951-682	1968-72 Clutch Pedal Pushrod	FedEx/UPS	\$ 24.95 ea
	4032-951-683A	1968-72 Clutch Pedal Pushrod Seal Retainer	FedEx/UPS	\$ 19.95 ea
	4041-951-587S	1968-72 Clutch Bellcrank Pivot Kit (nylon seals and springs)	FedEx/UPS	\$ 6.95 kit
	4041-951-589P	1968-72 Clutch Bellcrank Pivot Felt Seals (pair for one car)	FedEx/UPS	\$ 5.95 pr
	4010-951-652	1968-72 Bellcrank Engine Pivot Stud	FedEx/UPS	\$ 9.95 ea
	4010-951-651	1968-69 Bellcrank Frame Pivot Stud	FedEx/UPS	\$ 9.95 ea
	4046-951-694	1970-72 Bellcrank Frame Pivot Stud	FedEx/UPS	\$ 14.95 ea
	4032-951-685	1968-72 Chevelle / El Camino Bellcrank Frame Pivot Bracket	FedEx/UPS	\$ 14.95 ea
	4012-951-692S	1968-72 Clutch Lower Pushrod and Swivel	FedEx/UPS	\$ 19.95 set
	4033-951-712	1968-72 Clutch Fork Return Spring	FedEx/UPS	\$ 9.95 ea
	4020-951-6713	1968-72 Clutch Fork	FedEx/UPS	\$ 59.95 ea
	4030-951-6413	1968-72 Clutch Fork Boot	FedEx/UPS	\$ 9.95 ea
<b>Master Body Hardware Kits</b>				
<b>All the hardware you need to properly assembly your car's body bumper to bumper in one box!</b>				
	4032-958-68S	1968 Chevelle (360 pieces)	FedEx/UPS	\$ 179.95 set
	4032-958-69S	1969 Chevelle (384 pieces)	FedEx/UPS	\$ 179.95 set
	4033-958-70S	1970 Chevelle (407 pieces)	FedEx/UPS	\$ 189.95 set
	4033-958-71S	1971-72 Chevelle (370 pieces)	FedEx/UPS	\$ 189.95 set
	4060-958-70S	1970 Monte Carlo (407 pieces)	FedEx/UPS	\$ 189.95 set
	4060-958-71S	1971-72 Monte Carlo (408 pieces)	FedEx/UPS	\$ 189.95 set
<b>Speedometer Cable Grommet</b>				
	4030-985-64	1968-72	FedEx/UPS	\$ 6.95 ea
<b>Body Mount Bushings and Hardware</b>				
	4032-990-681S	1968-72 (except Convertible or Monte Carlo) Bushing Set	FedEx/UPS	\$ 89.95 set
	4032-990-683S	1968-69 (except Convertible) Bushing Hardware Set	FedEx/UPS	\$ 29.95 set
	4033-990-701S	1970-72 (except Convertible or Monte Carlo) Bushing Hardware Set	FedEx/UPS	\$ 29.95 set
	4032-990-682S	1968-72 Convertible Bushing Set	FedEx/UPS	\$ 99.95 set
	4032-990-684S	1968-69 Convertible Bushing Hardware Set	FedEx/UPS	\$ 29.95 set
	4033-990-702S	1970-72 Convertible Bushing Hardware Set	FedEx/UPS	\$ 29.95 set
	4060-990-70S	1970-72 Monte Carlo Bushing Set	FedEx/UPS	\$ 79.95 set
	4060-990-701S	1970-72 Monte Carlo Bushing Hardware Set	FedEx/UPS	\$ 59.95 set

If you don't find the item you are looking for, give us a call at 770-413-9126 or send an [Email](#). New parts are always in the works .

Prices and availability are subject to change without notice.  
Prices do not include shipping.

#### Shipping

Most smaller parts and shipments are shipped FedEx ground or UPS.

Parts marked as "Truck" are too large for FedEx or UPS and must be shipped by truck.

Most truck lines charge additional rates or surcharges for residential deliveries.

The best rates are to a business in a commercial zoned area or you pick up from the truck terminal.

Chevrolet, Pontiac, Oldsmobile, Buick, GMC, Chevy II, Nova, Camaro, Rally Sport, Z/28, "SS", Type LT, Berlinetta, Firebird, Esprit, Formula, Trans Am, 400, Chevelle, Malibu, SS-396, El Camino, Monte Carlo, Tempest, LeMans, GTO, Grand Prix, F-85, Cutlass, Cutlass Supreme, 4-4-2, Special, Skylark, GS, Biscayne, Bel Air, Impala, Caprice, S-10, S-15, Sonoma, Syclone, Typhoon, CST, Cheyenne, Suburban, Blazer, Jimmy, Tahoe, Yukon, Sprint, and Caballero are trademarks of General Motors Corporation.

All descriptions using trademarked names are for reference purposes only.

Copyright © WSC Motorsports 1991-2005 All Rights Reserved.

Revised Mar 3, 2005